



### FOREWORD


This handbook contains information on the Triumph Daytona 675 and Street Triple motorcycles. Always store this owner's handbook with the motorcycle and refer to it for information whenever necessary.



### Warnings, Cautions and Notes

Throughout this owner's handbook particularly important information is presented in the following form:

 <b>Warning</b>
This warning symbol identifies special instructions or procedures, which if not correctly followed could result in personal injury, or loss of life.

 <b>Caution</b>
This caution symbol identifies special instructions or procedures, which, if not strictly observed, could result in damage to, or destruction of, equipment.


#### Note:

- **This note symbol indicates points of particular interest for more efficient and convenient operation.**

## Foreword

---

### Warning Labels



At certain areas of the motorcycle, the symbol (left) can be seen. The symbol means 'CAUTION: REFER TO THE HANDBOOK' and will be followed by a pictorial representation of the subject

concerned.

Never attempt to ride the motorcycle or make any adjustments without reference to the relevant instructions contained in this handbook.

See page 10 for the location of all labels bearing this symbol. Where necessary, this symbol will also appear on the pages containing the relevant information.

### Maintenance

To ensure a long, safe and trouble free life for your motorcycle, maintenance should only be carried out by an authorised Triumph dealer. Only an authorised Triumph dealer will have the necessary knowledge, equipment and skills to maintain your Triumph motorcycle correctly.

To locate your nearest Triumph dealer, visit the Triumph web site at [www.triumph.co.uk](http://www.triumph.co.uk) or telephone the authorised distributor in your country. Their address is given in the service record book that accompanies this handbook.

### Noise Control System

Tampering with the Noise Control System is Prohibited.

Owners are warned that the law may prohibit:

- The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use and,
- the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

## Foreword

---

### Owner's Handbook

Thank you for choosing a Triumph motorcycle. This motorcycle is the product of Triumph's use of proven engineering, exhaustive testing, and continuous striving for superior reliability, safety and performance.

Please read this owner's handbook before riding in order to become thoroughly familiar with the correct operation of your motorcycle's controls, its features, capabilities and limitations.

This handbook includes safe riding tips, but does not contain all the techniques and skills necessary to ride a motorcycle safely.

Triumph strongly recommends that all riders undertake the necessary training to ensure safe operation of this motorcycle.

### Information

The information contained in this publication is based on the latest information available at the time of printing. Triumph reserves the right to make changes at any time without prior notice, or obligation.

Not to be reproduced wholly or in part without the written permission of Triumph Motorcycles Limited.

© Copyright 04.2008 Triumph Motorcycles Limited, Hinckley, Leicestershire, England.

Publication part number 3852801 issue 2.

### Warning

This owner's handbook, and all other instructions that are supplied with your motorcycle, should be considered a permanent part of your motorcycle and should remain with it even if your motorcycle is subsequently sold.

All riders must read this owner's handbook and all other instructions which are supplied with your motorcycle, before riding, in order to become thoroughly familiar with the correct operation of your motorcycle's controls, its features, capabilities and limitations. Do not lend your motorcycle to others as riding when not familiar with your motorcycle's controls, features, capabilities and limitations can lead to an accident.

## Foreword

---

### Table of Contents

This handbook contains a number of different sections. The table of contents below will help you find the beginning of each section where, in the case of the major sections, a further table of contents will help you find the specific subject required.

Foreword .....	1
Warning Labels .....	10
Parts Identification .....	14
Serial Numbers .....	19
General Information .....	21
How to Ride the Motorcycle .....	51
Accessories, Loading and Passengers .....	61
Maintenance and Adjustment .....	65
Storage .....	113
Specifications .....	115

### FOREWORD - SAFETY FIRST

#### The Motorcycle

 **Warning**

This motorcycle is designed for on-road use only. It is not suitable for off-road use. Off-road operation could lead to loss of control of the motorcycle resulting in an accident causing injury or loss of life.

 **Warning**

This motorcycle is not designed to tow a trailer or be fitted with a sidecar. Fitting a sidecar and/or a trailer may result in loss of control and an accident.

 **Warning**

This motorcycle is designed for use as a two-wheeled vehicle capable of carrying a rider on his/her own, or a rider and one passenger (subject to a passenger seat being fitted).

The total weight of the rider, and any passenger, accessories and luggage must not exceed the maximum load limit of 195 kg.

#### Fuel and Exhaust Fumes

 **Warning**

**PETROL IS HIGHLY FLAMMABLE:**

Always turn off the engine when refuelling. Do not refuel or open the fuel filler cap while smoking or in the vicinity of any open (naked) flame.

Take care not to spill any petrol on the engine, exhaust pipes or silencers when refuelling.

If petrol is swallowed, inhaled or allowed to get into the eyes, seek immediate medical attention.

Spillage on the skin should be immediately washed off with soap and water and clothing contaminated with petrol should immediately be removed.

Burns and other serious skin conditions may result from contact with petrol.

 **Warning**

Never start your engine or let it run for any length of time in a closed area. The exhaust fumes are poisonous and may cause loss of consciousness and death within a short time. Always operate your motorcycle in the open-air or in an area with adequate ventilation.

## Foreword - Safety First

---

### Helmet and Clothing

#### Warning

When riding the motorcycle, both rider and passenger must always wear a motorcycle helmet, eye protection, gloves, trousers (close fitting around the knee and ankle) and a brightly coloured jacket. Brightly coloured clothing will considerably increase a rider's (or passenger's) visibility to other operators of road vehicles. Although full protection is not possible, wearing correct protective clothing can reduce the risk of injury when riding.

#### Warning

A helmet is one of the most important pieces of riding gear as it offers protection against head injuries. You and your passenger's helmet should be carefully chosen and should fit you or your passenger's head comfortably and securely. A brightly coloured helmet will increase a rider's (or passenger's) visibility to other operators of road vehicles.

An open face helmet offers some protection in an accident though a full face helmet will offer more.

Always wear a visor or approved goggles to help vision and to protect your eyes.



### Parking

#### Warning

Always turn off the engine and remove the ignition key before leaving the motorcycle unattended. By removing the key, the risk of use of the motorcycle by unauthorised or untrained persons is reduced.

When parking the motorcycle, always remember the following:

Engage first gear to help prevent the motorcycle from rolling off the stand.

The engine and exhaust system will be hot after riding. DO NOT park where pedestrians, animals and/or children are likely to touch the motorcycle.

Do not park on soft ground or on a steeply inclined surface. Parking under these conditions may cause the motorcycle to fall over.

For further details, please refer to the 'How to Ride the Motorcycle' section of this owner's handbook.

## Foreword - Safety First

### Parts and Accessories

#### Warning

Owners should be aware that the only approved parts, accessories and conversions for any Triumph motorcycle are those which carry official Triumph approval and are fitted to the motorcycle by an authorised dealer.

In particular, it is extremely hazardous to fit or replace parts or accessories whose fitting requires the dismantling of, or addition to, either the electrical or fuel systems and any such modification could cause a safety hazard.

The fitting of any non-approved parts, accessories or conversions may adversely affect the handling, stability or other aspect of the motorcycle operation that may result in an accident causing injury or death.

Triumph does not accept any liability whatsoever for defects caused by the fitting of non-approved parts, accessories or conversions or the fitting of any approved parts, accessories or conversions by non-approved personnel.

### Maintenance/Equipment

#### Warning


Consult your authorised Triumph dealer whenever there is doubt as to the correct or safe operation of this Triumph motorcycle.

Remember that continued operation of an incorrectly performing motorcycle may aggravate a fault and may also compromise safety.

#### Warning

Use of a motorcycle with bank angle indicators worn beyond the maximum limit (when 5 mm of the bank indicator remains) will allow the motorcycle to be banked to an unsafe angle.

Banking to an unsafe angle may cause instability, loss of motorcycle control and an accident.



1. Bank angle indicator

## Foreword - Safety First

---

### **Warning**

Ensure all equipment that is required by law is installed and functioning correctly. The removal or alteration of the motorcycle's lights, silencers, emission or noise control systems can violate the law. Incorrect or improper modification may adversely affect the handling, stability or other aspect of the motorcycle operation, which may result in an accident causing injury or death.

### **Warning**

If the motorcycle is involved in an accident, collision or fall, it must be taken to an authorised Triumph dealer for inspection and repair. Any accident can cause damage to the motorcycle that, if not correctly repaired, may cause a second accident that may result in injury or death.

## Riding

### **Warning**

Never ride the motorcycle when fatigued or under the influence of alcohol or other drugs.

Riding when under the influence of alcohol or other drugs is illegal.

Riding when fatigued or under the influence of alcohol or other drugs reduces the rider's ability to maintain control of motorcycle and may lead to loss of control and an accident.

### **Warning**

All riders must be licensed to operate the motorcycle. Operation of the motorcycle without a licence is illegal and could lead to prosecution.

Operation of the motorcycle without formal training in the correct riding techniques that are necessary to become licenced is dangerous and may lead to loss of motorcycle control and an accident.

### **Warning**

Always ride defensively and wear the protective equipment mentioned elsewhere in this foreword. Remember, in an accident, a motorcycle does not give the same impact protection as a car.



## Foreword - Safety First

---

### **Warning**

This Triumph motorcycle should be operated within the legal speed limits for the particular road travelled. Operating a motorcycle at high speeds can be potentially dangerous since the time available to react to given traffic situations is greatly reduced as road speed increases. Always reduce speed in potentially hazardous driving conditions such as bad weather or heavy traffic.

### **Warning**

Continually observe and react to changes in road surface, traffic and wind conditions. All two-wheeled vehicles are subject to external forces which may cause an accident. These forces include but are not limited to:

- Wind draft from passing vehicles;
- Potholes, uneven or damaged road surfaces;
- Bad weather;
- Rider error.

Always operate the motorcycle at moderate speed and away from heavy traffic until you have become thoroughly familiar with its handling and operating characteristics. Never exceed the legal speed limit.

## Handlebars and Footrests

### **Warning**

The rider must maintain control of the vehicle by keeping hands on the handlebars at all times.

The handling and stability of a motorcycle will be adversely affected if the rider removes his hands from the handlebars, resulting in loss of motorcycle control and an accident.

### **Warning**

The rider and passenger must always use the footrests provided, during operation of the vehicle.


By using the footrests, both rider and passenger will reduce the risk of inadvertent contact with any motorcycle components and will also reduce the risk of injury from entrapment of clothing.

## Warning Labels

### WARNING LABELS


The labels detailed on this and the following pages draw your attention to important safety information in this handbook. Before riding, ensure that all riders have understood and complied with all the information to which these labels relate.

#### Warning Label Locations - Daytona 675




# Warning Labels

## Warning Label Locations - Daytona 675 (continued)




## Warning Labels

### Warning Label Locations - Street Triple



# Warning Labels


## Warning Labels Location - Street Triple (continued)



## Parts Identification

### PARTS IDENTIFICATION

#### Daytona 675




tdku

- |                                  |                            |
|----------------------------------|----------------------------|
| 1. Front indicator               | 8. Gear-change pedal       |
| 2. Headlight                     | 9. Front brake disc        |
| 3. Rear light                    | 10. Front brake caliper    |
| 4. Radiator/Coolant pressure cap | 11. Fuel tank              |
| 5. Oil cooler/Heat exchanger     | 12. Fuel filler cap        |
| 6. Drive chain                   | 13. Seat lock              |
| 7. Side stand                    | 14. Coolant expansion tank |

## Parts Identification

---

### Daytona 675 (continued)



15. Battery

16. Tool kit

17. Rear brake disc

18. Rear brake caliper

19. Rear brake fluid reservoir

20. Rear suspension unit

21. Oil filler cap

22. Clutch cable

23. Front fork


24. Rear brake pedal

25. Dipstick

26. Silencer

## Parts Identification

### Street Triple




- |                                  |                            |
|----------------------------------|----------------------------|
| 1. Front indicator               | 8. Gear-change pedal       |
| 2. Headlight                     | 9. Front brake disc        |
| 3. Rear light                    | 10. Front brake caliper    |
| 4. Radiator/Coolant pressure cap | 11. Fuel tank              |
| 5. Oil cooler/Heat exchanger     | 12. Fuel filler cap        |
| 6. Drive chain                   | 13. Seat lock              |
| 7. Side stand                    | 14. Coolant expansion tank |



## Parts Identification

### Street Triple (continued)



**15. Battery**

**16. Tool kit**

**17. Rear brake disc**

**18. Rear brake caliper**

**19. Rear brake fluid reservoir**

**20. Rear suspension unit**

**21. Oil filler cap**

**22. Clutch cable**

**23. Front fork**


**24. Rear brake pedal**

**25. Dipstick**

**26. Silencer**

## Parts Identification


### Both Models (Daytona 675 shown)



- |                                |                           |
|--------------------------------|---------------------------|
| 1. Clutch lever                | 8. Front brake lever      |
| 2. Passing button              | 9. Engine stop switch     |
| 3. Headlight dip switch        | 10. Starter button        |
| 4. Horn button                 | 11. Tachometer            |
| 5. Direction indicator switch  | 12. Speedometer           |
| 6. Ignition switch             | 13. Warning lights        |
| 7. Front brake fluid reservoir | 14. Trip computer display |

**SERIAL NUMBERS**

**Vehicle Identification Number (VIN)**




**1. VIN number (Daytona 675 shown)**

The Vehicle Identification Number (VIN) is stamped into the steering head area of the frame. It is also displayed on a plate, riveted to the frame, on the left hand side of the steering head.

Record the vehicle identification number in the space below.

**Engine Serial Number**



**1. Engine serial number (Daytona 675 shown)**

The engine serial number is stamped on the engine crankcase, immediately above the clutch cover.

Record the engine serial number in the space provided below.

## Serial Numbers

---

This page intentionally left blank

**GENERAL INFORMATION**

**Table of Contents**

Instrument Panel Layout (Daytona 675 shown) . . . . . 23

Speedometer and Odometer . . . . . 24

Tachometer . . . . . 24

Odometer/Trip Meter . . . . . 24

Clock/Trip Computer . . . . . 25

    Trip Computer Operation . . . . . 26

    Clock Adjustment . . . . . 26

    Trip Computer Reset . . . . . 27

    Lap Timer . . . . . 27

    Data Recording Mode . . . . . 28

    Data Retrieval Mode . . . . . 29

Gear Change Lights . . . . . 31

    Gear Change Light Modes . . . . . 32

    Adjusting Gear Change Light Modes . . . . . 32

    Setting Gear Change Light Limits . . . . . 34

Gear Position Display . . . . . 35

Coolant Temperature Gauge . . . . . 36

Warning Lights . . . . . 37

    Direction Indicators . . . . . 37

    High Beam . . . . . 37

    Low Fuel . . . . . 37

    Neutral . . . . . 37

    Low Oil Pressure Warning Light . . . . . 37

    High Coolant Temperature Warning Light . . . . . 37

    Engine Management System Malfunction Indicator Light . . . . . 38

    Alarm Indicator Light . . . . . 38

Ignition Key . . . . . 39

Ignition Switch/Steering Lock . . . . . 39

    Ignition Switch Positions . . . . . 39


## General Information

---

Brake Lever Adjuster .....	40
Right Handlebar Switches .....	41
Engine Stop Switch .....	41
Starter Button .....	42
Left Handlebar Switches .....	42
Headlight Dip Switch .....	42
Direction Indicator Switch .....	43
Horn Button .....	43
Pass Button .....	43
Fuel Requirement/Refuelling .....	43
Fuel Grade .....	43
Fuel Tank Cap .....	44
Filling the Fuel Tank .....	45
Tool Kit and Handbook .....	45
Stand .....	46
Side Stand .....	46
Seat Lock .....	47
Seat Care .....	47
Rider's Seat .....	47
Rear Seat/Seat Cover .....	48
Running-In .....	48
Safe Operation .....	49
Daily Safety Checks .....	49

## General Information

### Instrument Panel Layout (Daytona 675 shown)



1. Tachometer
2. Tachometer 'red zone'
3. Speedometer
4. Odometer/Trip meters
5. Clock/Trip computer display
6. Scroll/Set/Trip buttons
7. Coolant temperature display
8. Low oil pressure warning light
9. High coolant temperature warning light
10. Engine management malfunction indicator light
11. Low fuel level indicator light
12. Neutral indicator light
13. High beam indicator light
14. Direction indicator light
15. Gear change lights
16. Alarm status indicator light (alarm is an accessory fit)
17. Gear position indicator

## General Information

### Speedometer and Odometer

The digital speedometer indicates the road speed of the motorcycle. The read-out displays the motorcycle road speed in increments of one kilometre (or mile) per hour.

In the speedometer face is the electronic odometer and two trip meters. For details of the operation of the odometer and trip meters, please refer to the following pages.


### Tachometer

The tachometer shows the engine speed in revolutions per minute - rpm (r/min). On the right side of the tachometer face is the 'red zone'. Engine rpm (r/min) in the red zone is above maximum recommended engine speed and is also above the range for best performance.

#### Caution

Never allow engine rpm to enter the 'red zone' as severe engine damage may result.

### Odometer/Trip Meter



1. Odometer/Trip meter display
2. Set button
3. Trip button
4. Trip meter 1 display
5. Trip meter 2 display

The odometer shows the total distance that the motorcycle has travelled.

The odometer and two trip meters are located in the same display frame as the speedometer. Either trip meter shows the distance that the motorcycle has travelled since the meter on display was last reset to zero.

#### Warning

Do not attempt to switch between odometer and trip meter display modes or reset the trip meter with the motorcycle in motion as this may lead to loss of motorcycle control and an accident.




## General Information

Use the 'Trip' button to switch between the odometer and trip meter display modes. Press the 'Trip' button repeatedly until the desired display is visible. The display will scroll through in the order:

- Odometer
- Trip Meter 1
- Trip Meter 2

To reset either of the trip meters, select and display the trip meter to be zeroed then press the 'Trip' and 'Set' buttons together for 2 seconds. After 2 seconds, the trip meter on display will reset to zero.

### Clock/Trip Computer



1. Clock/Trip computer display
2. Scroll button

The clock and trip computer information appear on the same display.

The trip computer provides an indication of fuel consumption, speed, lap time, time and distance, all recorded and calculated since the last reset.

Each display provides the following information:

#### Instantaneous Fuel Consumption

An indication of the fuel consumption at an instant in time.

#### Average Fuel Consumption

An indication of the average fuel consumption, calculated from when the trip computer was last reset. After a reset the display will show dashes until 0.1 miles/km has been covered.

#### Journey Distance

The total distance travelled, since the last reset.

## General Information

---

### Journey Time

The total time elapsed, since the last reset.

### Average Speed

The average speed is calculated from when the trip computer was last reset. After a reset the display will show dashes until 1 mile/km has been covered.

### Maximum Speed

The maximum speed achieved since the last reset is displayed.

### Lap Timer

Provides information on lap time, maximum speed, average speed, and distance travelled for up to 99 laps.

### Trip Computer Operation

#### Display Section

When the ignition is switched on the clock display is shown. To access the trip computer information press the 'Scroll' button.


Press the 'Scroll' button repeatedly until the desired display is visible. The trip display will scroll through in the order:

- Clock
- Lap Timer
- Average Speed
- Maximum Speed
- Journey Distance
- Journey Time
- Average Fuel Consumption
- Instantaneous Fuel Consumption

### Clock Adjustment

#### Warning

Do not attempt to adjust the clock with the motorcycle in motion as this may lead to loss of motorcycle control and an accident.



1. Clock display
2. Hours read-out
3. Minutes read-out
4. Scroll button
5. Set button

To reset the clock, select the clock display and press both 'Scroll' and 'Set' buttons together. After a short time, the clock's hour display will start to flash.

To reset the hour display, ensure that the hour display is still flashing then depress the 'Scroll' button to change the setting. Each individual press will change the setting by one digit.


When the correct hour display is shown, press the 'Set' button. The minutes display

## General Information

will begin to flash. The minutes display is adjusted in the same way as for the hours.

Once both hours and minutes are correctly set, press the 'Set' button to confirm the setting. The display will cease to flash.

### Trip Computer Reset




1. Trip computer display
2. Scroll button
3. Set button

### Warning

Do not attempt to switch between the trip computer display modes or reset the trip computer with the motorcycle in motion as this may lead to loss of motorcycle control and an accident.

To reset the trip computer only, select one of the trip computer displays, press the 'Scroll' and 'Set' buttons simultaneously for 2 seconds. After 2 seconds, the trip computer, not the clock, will reset.

### Lap Timer



#### 1. Lap timer display

The lap timer will provide the following information: Lap time, number of laps, maximum speed, average speed and distance travelled. Each display provides the following information:

#### Lap Time

The elapsed time of the lap (the lap number will be displayed in the speedometer display position). Information is recorded for each lap since the last reset.

#### Note:

- **The lap timer will record up to 99 minutes, 59 seconds and 9 tenths of a second. After this time, the display will reset to zero.**

#### Number of Laps

The number of recorded laps since the last reset is displayed. Up to a maximum of 99 laps can be stored by the lap timer.

## General Information

### Maximum Speed

The maximum speed achieved per lap (the lap number will be displayed in the speedometer display position) or the maximum speed achieved during all recorded laps.

### Average Speed

The average speed per lap (the lap number will be displayed in the speedometer display position) or the average speed during all recorded laps.

### Distance Travelled


The distance travelled per lap (the lap number will be displayed in the speedometer display position) or the distance travelled for all recorded laps.

The lap timer has two modes; Data Recording Mode and Data Retrieval Mode.

### Warning

Do not attempt to switch between lap timer display modes with the motorcycle in motion as this may lead to loss of motorcycle control and an accident.

### Data Recording Mode



1. Lap time display (during a lap)
2. Stop watch icon
3. Scroll button


After pressing the 'Scroll' button to select the lap timer, the word 'LAP' will appear in the clock display.

Pressing the starter button (with the engine running only) will start the lap timer. The display will show the lap time in minutes, seconds and tenths of a second, and the stop watch icon will flash.

At the end of the lap, pressing the starter button again will register the start of a new lap. The display will show the last lap time for 15 seconds. After this time, the display will show the current lap number for 5 seconds before returning to the time for the current lap.

## General Information


### New Lap Recording



#### 1. Starter button

Each new lap is recorded by a brief press of the starter button (with the engine running only). Whilst in the data recording mode, pressing the starter button for 2 seconds will return the display to the lap timer. From the lap timer display, press the 'Set' button to enter the Data Retrieval Mode.

### Data Retrieval Mode



1. Lap time
2. Lap number
3. Set button
4. Trip button

#### Accessing the Data Retrieval Mode

The Data Retrieval Mode can be accessed in one of two ways:


- With the ignition in the ON position, from the lap timer display, press the 'Set' button.
- From the Data Recording Mode, with the engine running and the motorcycle stationary, press the starter button for 2 seconds. This will return the display to the 'LAP' display. From here press the 'Set' button.

The Data Retrieval Mode cannot be accessed whilst the motorcycle is in motion.

## General Information

### Data Retrieval Mode

When the Data Retrieval Mode is accessed, the lap time for the first lap will be displayed. The lap number will be displayed in the speedometer display position. The stop watch icon will no longer flash.




1. Data Retrieval Mode (lap time shown)
2. Lap number
3. Scroll button
4. Trip button

Press the 'Trip' button repeatedly until the desired lap (up to a maximum of 99 laps) is displayed.

Press the 'Scroll' button repeatedly until the desired data is visible for the lap number displayed.

The lap timer display will scroll through in the order:

- Lap Time
- Maximum Speed (per lap or maximum speed achieved)
- Average Speed (per lap or total of all laps)
- Distance Travelled (per lap or total of all laps)



1. Data Retrieval Mode (maximum speed shown)
2. Lap number
3. Scroll button
4. Trip button


The speed and distance will be displayed in kilometres or miles, according to the units displayed by the speedometer.

After the last lap is displayed, the total time for all laps, from the last reset will be displayed.

## General Information

The letters 'Ltt' will appear in the speedometer display. Pressing the 'Scroll' button repeatedly will display the following:

- Total Time for All Laps
- Maximum Speed Achieved
- Average Speed of All Laps
- Total Distance Travelled




1. Data Retrieval Mode - total time display
2. Lap timer 'total time' indication
3. Scroll button

### Lap Timer Reset

To reset the lap timer, press the 'Scroll' and 'Set' buttons simultaneously for 2 seconds. After 2 seconds, the lap timer will reset. This will delete the stored data for all stored laps.

To exit the Data Retrieval Mode, press the 'Set' button.

## Gear Change Lights



1. Gear change lights
2. Display screen
3. Scroll button
4. Set button
5. Trip button

The gear change lights provide a visual indication of when to change gear. The set change-up speed at which the lights operate can be adjusted for rider preference. The gear change lights are all coloured blue.

## General Information

### Gear Change Light Modes

The gear change lights have four programmable operating modes as described below:

- **SCALE mode:** The lights will illuminate in sequence 3,000 rpm before the set change-up speed in the following order:

LED	RPM
1 <sup>st</sup> LED	3,000 rpm before set change-up speed
2 <sup>nd</sup> LED	2,250 rpm before set change-up speed
3 <sup>rd</sup> LED	1,500 rpm before set change-up speed
4 <sup>th</sup> LED	750 rpm before set change-up speed
5 <sup>th</sup> , 6 <sup>th</sup> and 7 <sup>th</sup> LEDs	At set change-up speed

The gear change lights will go out in the reverse of the order in which they illuminate.


- **3 LED mode:** The three middle lights illuminate when the set limit is reached, and remain illuminated until the engine speed drops below the set limit.
- **7 LED mode:** All seven lights illuminate when the set limit is reached, and remain illuminated until the engine speed drops below the set limit.
- **OFF mode:** The gear change lights can be set to OFF.

The gear change lights will not operate below 4,000 rpm to avoid the lights operating at idle, and will not operate above 14,000 rpm.

### Adjusting Gear Change Light Modes

To adjust the gear change light modes, turn the ignition to the ON position.

Press the 'Trip' and 'Scroll' buttons simultaneously for 4 seconds, after 4 seconds the current mode will be displayed.




1. Gear change lights
2. Display screen (3 LED mode shown)
3. Scroll button
4. Set button
5. Trip button



## General Information


The corresponding lights for the current mode will be illuminated and the clock will display the selected mode - either SCALE, LEd 3, LEd 7, or OFF. If the OFF mode has been selected, no lights will be illuminated. See 'Gear Change Light Modes' on page 32.



1. Gear change lights
2. Display screen (SCALE mode shown)

To scroll through the four modes press the 'Set' button. To set the gear change lights to the displayed mode, press the 'Trip' and 'Scroll' buttons simultaneously for 4 seconds.

If the OFF mode is selected at this point, the instruments will return to their normal mode of operation, otherwise the gear change lights limits can now be adjusted as described below:




1. Gear change lights
2. Display screen (OFF mode shown)

## General Information

### Setting Gear Change Light Limits


Select the desired gear change light mode as described above. Press the 'Trip' and 'Scroll' buttons simultaneously for 4 seconds. After 4 seconds, the tachometer needle will move round to the last set position and the word 'tAcHo' will appear in the clock display. The corresponding lights for the current mode will also remain illuminated.



1. Gear change lights
2. Display screen
3. Scroll button
4. Set button
5. Trip button

Pressing the 'Set' button at this point will return the instruments to their normal mode of operation, without adjusting the gear change lights limits.

To change the setting, press the 'Scroll' button. The clock display will now show 'A1000'.




1. Gear change lights
2. Display screen
3. Scroll button
4. Set button
5. Trip button

To change the setting in increments of 1,000 rpm, press the 'Scroll' button again. Each individual press will then increase the setting in increments of 1,000 rpm, up to a limit of 14,000 rpm. As the limit cannot exceed 14,000 rpm, when 14,000 rpm is reached the limit will return to 4,000 rpm.

## General Information

When the correct setting is shown press the 'Set' button to confirm. The clock display will now show 'A100'.



1. Gear change lights
2. Display screen
3. Scroll button
4. Set button
5. Trip button


The setting can now be changed in increments of 100 rpm, again up to a limit of 14,000 rpm.

Each individual press of the 'Scroll' button will increase the setting in increments of 100 rpm, up to a limit of 14,000 rpm. As the limit cannot exceed 14,000, when 14,000 rpm is reached, the limit will return to 4,000 rpm.

When the correct setting is shown, pressing the 'Set' button will confirm the setting.


When the gear change lights settings are exited in any mode except OFF, the tachometer needle will quickly sweep from zero to maximum and then return to zero, and the gear change lights will illuminate according to their set mode.

## Gear Position Display



1. Gear position display (neutral position shown)

The gear position display indicates the gear position. When the transmission is in neutral (no gear selected), the display will show 'n'.




1. Gear position display (fifth gear shown)

When the transmission is in gear the relevant gear number '1' to '6' will be displayed.

## General Information

---

### Coolant Temperature Gauge



#### 1. Coolant temperature gauge

The coolant temperature gauge indicates the temperature of the engine coolant.

When the ignition is switched on, all 10 bars of the display will be shown. When the engine is started from cold the display will show 1 bar. As the temperature increases more bars will be shown in the display. When the engine is started from hot the display will show the relevant number of bars, dependant on engine temperature.

The normal temperature range is between 3 and 6 bars.

If the coolant temperature becomes too high the display will show 9 bars and will start to flash. The high coolant temperature warning light in the tachometer will also be illuminated.

If the coolant temperature increases further, all 10 bars of the display will flash. The high temperature warning light in the tachometer will remain illuminated.

#### **Caution**

Do not continue to run the engine if either of the high temperature warnings are displayed as severe engine damage may result.

## General Information

### Warning Lights

#### Direction Indicators



When the indicator switch is pushed to the left or right, the turn indicator light will flash on and off at the same speed as the turn indicators.

#### High Beam



When the ignition is switched on and the headlight dip switch is set to 'high beam', the high beam warning light will illuminate.

#### Low Fuel



The low fuel indicator will illuminate when there are approximately 3.0 litres of fuel remaining in the tank.

#### Neutral



The neutral warning light indicates when the transmission is in neutral (no gear selected). The warning light will illuminate when the transmission is in neutral with the ignition switch in the ON position.

#### Low Oil Pressure Warning Light



With the engine running, if the engine oil pressure becomes dangerously low, the low oil pressure warning light in the tachometer will illuminate.

#### Caution

Stop the engine immediately if the low oil pressure warning light illuminates. Do not restart the engine until the fault has been rectified.

Severe engine damage will result from running the engine when the low oil pressure warning light is illuminated.

The low oil pressure warning light in the tachometer will illuminate if the ignition is switched on without running the engine.

#### High Coolant Temperature Warning Light



With the engine running, if the engine coolant temperature becomes dangerously high, the high coolant temperature warning light in the tachometer will illuminate.

#### Caution

Stop the engine immediately if the high coolant temperature warning light illuminates. Do not restart the engine until the fault has been rectified.

Severe engine damage will result from running the engine when the high coolant temperature warning light is illuminated.

The high coolant temperature warning light in the tachometer will illuminate if the ignition is switched on without running the engine.

## General Information

---

### Engine Management System Malfunction Indicator Light



The malfunction indicator light for the engine management system illuminates when the ignition is switched on (to indicate that it is working), but should not become illuminated when the engine is running.

If the malfunction indicator light becomes illuminated when the engine is running, this indicates that a fault has occurred in one or more of the systems controlled by the engine management system. In such circumstances, the engine management system will switch to 'limp-home' mode so that the journey may be completed, if the fault is not so severe that the engine will not run.

#### **Warning**

Reduce speed and do not continue to ride for longer than is necessary with the malfunction indicator light illuminated. The fault may adversely affect engine performance, exhaust emissions and fuel consumption. Reduced engine performance could cause a dangerous riding condition, leading to loss of control and an accident. Contact an authorised Triumph dealer as soon as possible to have the fault checked and rectified.

#### **Note:**

- **If the malfunction indicator light flashes when the ignition is switched on, contact an authorised Triumph dealer as soon as possible to have the situation rectified. In these circumstances the engine will not start.**

### Alarm Indicator Light




The alarm light will illuminate when the conditions described in the accessory alarm instructions are met.

The light does not function unless an alarm is fitted.

## General Information

### Ignition Key



#### 1. Key number tag

In addition to operating the steering lock/ignition switch, the ignition key is required to operate the seat lock and fuel tank cap.


When the motorcycle is delivered from the factory, two keys are supplied together with a small tag bearing the key number. Make a note of the key number and store the spare key and key number tag in a safe place away from the motorcycle.

Your authorised Triumph dealer can supply a replacement key cut from details of the key number or can cut a new key using the original as a master.

#### **Caution**

Do not store the spare key with the motorcycle as this will reduce all aspects of security.

### Ignition Switch/Steering Lock



#### 1. Ignition switch/steering lock

#### 2. LOCK position

#### 3. OFF position

#### 4. ON position

#### 5. PARK position

#### Ignition Switch Positions

This is a four position, key operated switch. The key can be removed from the switch only when it is in the OFF, LOCK or P (PARK) position.

**TO LOCK:** Turn the key to the OFF position, push and fully release the key, then rotate it to the LOCK position.

**PARKING:** Turn the key from the LOCK position to the P position. The steering will remain locked.

#### Note:

- **Do not leave the steering lock in the P position for long periods of time as this will cause the battery to discharge.**

## General Information

### Warning

For reasons of security and safety, always move the ignition switch to the OFF position and remove the key when leaving the motorcycle unattended.


Any unauthorised use of the motorcycle may cause injury to the rider, other road users and pedestrians and may also cause damage to the motorcycle.

### Warning

With the key in the LOCK or P position the steering will become locked.

Never turn the key to the LOCK or P positions while the motorcycle is moving as this will cause the steering to lock. Locked steering will cause loss of motorcycle control and an accident.

## Brake Lever Adjuster



**1. Lever (Daytona 675 shown)**

**2. Adjuster wheel**

**3. Triangular mark**

An adjuster is fitted to the front brake lever. The adjuster allows the distance from the handlebar to the lever to be changed to one of six positions for Daytona 675 or four positions for Street Triple, to suit the span of the operator's hands.

To adjust the lever, push the lever forward and turn the adjuster wheel to align one of the numbered positions with the triangular mark on the lever holder.

The distance from the handlebar grip to the released lever is shortest when set to number six (Daytona 675), or four (Street Triple), and longest when set to number one.




## General Information

### Warning

Do not attempt to adjust the lever with the motorcycle in motion as this may lead to loss of motorcycle control and an accident. After adjusting the lever, operate the motorcycle in an area free from traffic to gain familiarity with the new lever setting. Do not loan your motorcycle to anyone as they may change the lever setting from the one you are familiar with causing loss of control or an accident.

### Right Handlebar Switches



1. Engine stop switch
2. Starter button

#### Engine Stop Switch

In addition to the ignition switch being turned to the ON position, the engine stop switch must be in the RUN position for the motorcycle to operate.

The engine stop switch is for emergency use. If an emergency arises which requires the engine to be stopped, move the engine stop switch to the STOP position.

#### Note:

- **Although the engine stop switch stops the engine, it does not turn off all the electrical circuits and may cause difficulty in restarting the engine due to a discharged battery. Ordinarily, only the ignition switch should be used to stop the engine.**

## General Information

---

### Caution

Do not leave the ignition switch in the ON position unless the engine is running as this may cause damage to electrical components and will discharge the battery.

#### Starter Button


The starter button operates the electric starter. For the starter to operate, the clutch lever must be pulled to the handlebar.

#### Note:

- **Even if the clutch lever is pulled to the handlebar, the starter will not operate if the side stand is down and a gear is engaged.**

With the engine running, the starter button functions as the lap timer 'trigger' button. Momentarily pressing the starter button will start the lap timer recording the next lap.

## Left Handlebar Switches



1. Headlight dip switch
2. Direction indicator switch
3. Horn button
4. Pass button

#### Headlight Dip Switch

High or low beam can be selected with the headlight dip switch. To select high beam, push the switch forward. To select low beam, push the switch rearwards. When the high beam is turned on, the high beam indicator light will illuminate.

#### Note:

- **A lighting on/off switch is not fitted to this model. The headlight, rear light and licence plate light all function automatically when the ignition is turned to the ON position.**

## General Information

### Direction Indicator Switch

When the indicator switch is pushed to the left or right and released, the corresponding direction indicators will flash on and off. To turn off the indicators, push and release the switch.

### Horn Button

When the horn button is pushed, with the ignition switch turned to the ON position, the horn will sound.

### Pass Button

When the pass button is pressed, the headlight main beam will be switched on. It will remain on as long as the button is held in and will turn off as soon as the button is released.

### Fuel Requirement/Refuelling

#### Fuel Grade



Your Triumph engine is designed to use unleaded fuel and will give optimum performance if the correct grade of fuel is used. Daytona 675 models require unleaded fuel with a MINIMUM octane rating of 95 RON. Street Triple models can use unleaded fuel with an octane rating of 91 RON or higher.

#### Caution

The exhaust system is fitted with a catalytic converter to help reduce exhaust emission levels. The catalytic converter can be permanently damaged if the motorcycle is allowed to run out of fuel or if the fuel level is allowed to get very low. Always ensure you have adequate fuel for your journey.

#### Caution

The use of leaded fuel is illegal in most countries, states or territories. Use of leaded fuel will damage the catalytic converter.

## General Information

### Warning

To help reduce hazards associated with refuelling, always observe the following fuel safety instructions:

Petrol (fuel) is highly flammable and can be explosive under certain conditions. When refuelling, turn the ignition switch to the OFF position.

Do not smoke.

Do not use a mobile telephone.


Make sure the refuelling area is well ventilated and free from any source of flame or sparks. This includes any appliance with a pilot light.

Never fill the tank until the fuel level rises into the filler neck. Heat from sunlight or other sources may cause the fuel to expand and overflow creating a fire hazard.

After refuelling always check that the fuel filler cap is correctly closed and locked.

Because petrol (fuel) is highly flammable, any fuel leak or spillage, or any failure to observe the safety advice given above will lead to a fire hazard, which could cause damage to property, injury to persons or death.

### Fuel Tank Cap



**1. Fuel tank cap**

**2. Key**

To open the fuel tank cap, lift up the flap covering the lock itself. Insert the key into the lock and turn the key clockwise.

To close and lock the cap, push the cap down into place with the key inserted, until the lock 'clicks' into place. Withdraw the key and close the key cover.

### Caution

Closing the cap without the key inserted will damage the cap, tank and lock mechanism.

## General Information


### Filling the Fuel Tank

Avoid filling the tank in rainy or dusty conditions where airborne material can contaminate the fuel.

#### **Caution**

Contaminated fuel may cause damage to fuel system components.

Fill the fuel tank slowly to help prevent spillage. Do not fill the tank to a level above the bottom of the filler neck. This will ensure there is enough air space to allow for fuel expansion if the fuel inside the tank expands through absorption of heat from the engine or from direct sunlight.



1. **Maximum fuel level**
2. **Fuel filler neck**
3. **Air space**

#### **Warning**

Overfilling the tank can lead to fuel spillage.

If fuel is spilled, thoroughly clean up the spillage immediately and dispose of the materials used safely.

Take care not to spill any fuel on the engine, exhaust pipes, tyres or any other part of the motorcycle.

Because fuel is highly flammable, any fuel leak or spillage, or any failure to observe the safety advice given above may lead to a fire hazard, which could cause damage to property and injury or death to persons.

Fuel spilled near to, or onto the tyres will reduce the tyre's ability to grip the road. This will result in a dangerous riding condition potentially causing loss of motorcycle control and an accident.

After refuelling always check that the fuel filler cap is correctly closed and locked.

### Tool Kit and Handbook

The tool kit is located beneath the seat(s).


The handbook is located beneath the seat (rear seat on Daytona 675).

## General Information

---

### Stand

#### Side Stand



#### 1. Side stand

The motorcycle is equipped with a side stand on which the motorcycle can be parked.

#### Warning

The motorcycle is fitted with an interlock system to prevent it from being ridden with the side stand in the down position.

Never attempt to ride with the side stand down or interfere with the interlock mechanism as this will cause a dangerous riding condition leading to loss of motorcycle control and an accident.

#### Note:

- **When using the side stand, always turn the handlebars fully to the left and leave the motorcycle in first gear.**

Whenever the side stand is used, before riding, always ensure that the side stand is fully up after first sitting on the motorcycle.

For instructions on safe parking, refer to the 'How to Ride the Motorcycle' section.

## General Information

### Seat Lock

#### Seat Care

To prevent damage to the seat or seat cover, care must be taken not to drop or lean the seat against any surface which may damage the seat or seat cover.


#### Caution

To prevent damage to the seat or seat cover, care must be taken not to drop the seat. Do not lean the seat against the motorcycle or any surface which may damage the seat or seat cover. Instead, place the seat, with the seat cover facing upwards, on a clean, flat surface which is covered with a soft cloth.

Do not place any item on the seat which may cause damage or staining to the seat cover.

### Rider's Seat

#### Both Models



#### 1. Seat lock (Daytona 675 shown)

The seat lock is located on the left hand side of the battery tray, in line with the footrest mounting rail. To remove the seat, insert the ignition key into the seat lock and turn it anti-clockwise while pressing down on the rear of the seat. This will release the seat from its lock and allow it to be slid rearwards for complete removal from the motorcycle.

To refit the seat, engage the seat's tongue under the fuel tank and press down at the rear to engage in the seat lock.

#### Warning


To prevent detachment of the seat during riding, after fitting always grasp the seat and pull firmly upwards. If the seat is not correctly secured, it will detach from the lock. A loose or detached seat could cause loss of motorcycle control and an accident.

## General Information

---

### Rear Seat/Seat Cover

#### Daytona 675 only



#### 1. Rear seat fixing

To remove the rear seat cover or rear seat (where fitted): Remove the fixing located beneath the padding. This will allow the rear seat/seat cover to be slid forwards for complete removal from the motorcycle.

### Running-In



Running-in is the name given to the process that occurs during the first hours of a new vehicle's operation.

In particular, internal friction in the engine will be higher when components are new. Later on, when continued operation of the engine has ensured that the components have 'bedded in', this internal friction will be greatly reduced.

A period of careful running-in will ensure lower exhaust emissions, and will optimise performance, fuel economy and longevity of the engine and other motorcycle components.

During the first 500 miles (800 kilometres):

- Do not use full throttle.
- Avoid high engine speeds at all times.
- Avoid riding at one constant engine speed, whether fast or slow, for a long period of time.
- Avoid aggressive starts, stops, and rapid accelerations, except in an emergency.
- Do not ride at speeds greater than 3/4 of maximum engine speed.

From 500 to 1000 miles (800 to 1500 kilometres):

- Engine speed can gradually be increased to the rev limit for short periods.



## General Information

Both during and after running-in has been completed:

- Do not over-rev the engine when cold.
- Do not let the engine labour. Always downshift before the engine begins to 'struggle'.
- Do not ride with engine speeds unnecessarily high. Changing up a gear helps reduce fuel consumption, reduces noise and helps to protect the environment.

## Safe Operation

### Daily Safety Checks



Check the following items each day before you ride. The time required is minimal, and these checks will help ensure a safe, reliable ride.

If any irregularities are found during these checks, refer to the Maintenance and Adjustment section or see your authorised Triumph dealer for the action required to return the motorcycle to a safe operating condition.

### Warning

Failure to perform these checks every day before you ride may result in serious motorcycle damage or an accident causing serious injury or death.

Check:

**Fuel:** Adequate supply in tank, no fuel leaks (page 43).

**Engine Oil:** Correct level on dipstick. Add correct specification oil as required. No leaks from the engine or oil cooler (page 71).

**Drive Chain:** Correct adjustment (page 81).

**Tyres/Wheels:** Correct inflation pressures (when cold). Tread depth/wear, tyre/wheel damage, punctures etc. (page 94).

**Nuts, Bolts, Fasteners:** Visually check that steering and suspension components, axles, and all controls are properly tightened or

## General Information

---

fastened. Inspect all areas for loose/damaged fixings.

**Steering Action:** Smooth but not loose from lock to lock. No binding of any of the control cables (page 89).

**Brakes:** Pull the brake lever and push the brake pedal to check for correct resistance. Investigate any lever/pedal where the travel is excessive before meeting resistance, or if either control feels spongy in operation (page 84).

**Brake Pads:** There should be more than 1.5 mm of friction material remaining on all the pads (page 84).

**Brake Fluid Levels:** No brake fluid leakage. Brake fluid levels must be between the MAX and MIN marks on both reservoirs (page 84).

**Front Forks:** Smooth action. No leaks from fork seals (page 90).

**Throttle:** Throttle grip free play 2 - 3 mm. Ensure that the throttle grip returns to the idle position without sticking (page 77).

**Clutch:** Smooth operation and correct cable free play (page 80).

**Coolant:** No coolant leakage. Check the coolant level in the expansion tank (when the engine is cold) (page 74).

**Electrical Equipment:** All lights and the horn function correctly (page 39).

**Engine Stop:** Stop switch turns the engine off (page 52).

**Stands:** Returns to the fully up position by spring tension. Return springs not weak or damaged (page 46).

## How to Ride the Motorcycle

---


### HOW TO RIDE THE MOTORCYCLE

#### Table of Contents

To Stop the Engine.....	52
To Start the Engine.....	52
Moving Off.....	53
Changing Gears.....	54
Braking.....	55
Parking.....	57
Considerations for High-Speed Operation.....	58
General.....	58
Steering.....	58
Luggage.....	58
Brakes.....	58
Tyres.....	59
Fuel.....	59
Engine Oil.....	59
Coolant.....	59
Electrical Equipment.....	59
Miscellaneous.....	59

## How to Ride the Motorcycle

### To Stop the Engine



1. Engine stop switch
2. Starter button
3. Neutral indicator light
4. ON position
5. Ignition switch

Close the throttle completely.  
Select neutral.  
Turn the ignition switch off.  
Select first gear.  
Support the motorcycle on a firm, level surface with the side stand.  
Lock the steering.

#### Caution

The engine should normally be stopped by turning the ignition switch to the OFF position. The engine stop switch is for emergency use only. Do not leave the ignition switched on with the engine stopped. Electrical damage may result.

### To Start the Engine

Check that the engine stop switch is in the RUN position.

Ensure the transmission is in neutral.

Turn the ignition switch on.

#### Note:

- **When the ignition is switched on, the tachometer needle will quickly sweep from zero to maximum and then return to zero. The instrument warning lights will illuminate and will then go off (except those which normally remain on until the engine starts - see 'Warning Lights' on page 37). It is not necessary to wait for the needle to return to zero before starting the engine.**
- **In very cold conditions, part open the throttle to aid cold starting. Return it to the closed position once the engine has started.**

Pull the clutch lever fully into the handlebar.

## How to Ride the Motorcycle

---

Leaving the throttle fully closed, push the starter button until the engine starts.

### **Warning**

Never start the engine or run the engine in a confined area. Exhaust fumes are poisonous and can cause loss of consciousness and death within a short period of time. Always operate your motorcycle in the open-air or in an area with adequate ventilation.

### **Caution**

Do not operate the starter continuously for more than 5 seconds as the starter motor will overheat and the battery will become discharged. Wait 15 seconds between each operation of the starter to allow for cooling and recovery of battery power.

Do not let the engine idle for long periods as this may lead to overheating which will cause damage to the engine.

### **Caution**

The low oil pressure warning light should go out shortly after the engine starts.

If the low oil pressure warning light stays on after starting the engine, stop the engine immediately and investigate the cause. Running the engine with low oil pressure will cause severe engine damage.


- The motorcycle is equipped with starter lockout switches. The switches prevent the electric starter from operating when the transmission is not in neutral with the side stand down.
- If the side stand is extended whilst the engine is running, and the transmission is not in neutral then the engine will stop regardless of clutch position.

### **Moving Off**

Pull in the clutch lever and select first gear. Open the throttle a little and let out the clutch lever slowly. As the clutch starts to engage, open the throttle a little more, allowing enough engine speed to avoid stalling.

## How to Ride the Motorcycle

### Changing Gears



#### 1. Gear-change pedal



Close the throttle while pulling in the clutch lever. Change into the next higher or lower gear. Open the throttle part way, while releasing the clutch lever. Always use the clutch when changing gear.

#### Warning

Take care to avoid opening the throttle too far or too fast in any of the lower gears as this can lead to the front wheel lifting from the ground (pulling a 'wheelie') and to the rear tyre breaking traction (wheel spin).

Always open the throttle cautiously, particularly if you are unfamiliar with the motorcycle, as a 'wheelie' or loss of traction will cause loss of motorcycle control and an accident.

#### Note:


- The gear change mechanism is the 'positive stop' type. This means that, for each movement of the gear change pedal, you can only select each gear, one after the other, in ascending or descending order.

#### Warning


Do not change to a lower gear at speeds that will cause excessive engine rpm (r/min). This can lock the rear wheel causing loss of control and an accident. Engine damage may also be caused. Changing down should be done such that low engine speeds will be ensured.

## How to Ride the Motorcycle

### Braking



1. Front brake lever (Daytona 675 shown)



1. Rear brake pedal (Daytona 675 shown)

#### Warning

##### **WHEN BRAKING, OBSERVE THE FOLLOWING:**

Close the throttle completely, leaving the clutch engaged to allow the engine to help slow down the motorcycle.

Change down one gear at a time such that the transmission is in first gear when the motorcycle comes to a complete stop.

When stopping, always apply both brakes at the same time. Normally the front brake should be applied a little more than the rear.

Change down or fully disengage the clutch as necessary to keep the engine from stalling.

Never lock the brakes, as this may cause loss of control of the motorcycle and an accident.

#### Warning

For emergency braking, disregard down changing, and concentrate on applying the front and rear brakes as hard as possible without skidding. Riders should practice emergency braking in a traffic-free area.

Triumph strongly recommends that all riders take a course of instruction, which includes advice on safe brake operation. Incorrect brake technique could result in loss of control and an accident.

## How to Ride the Motorcycle

---

### Warning

For your safety, always exercise extreme caution when braking, accelerating or turning as any incautious action can cause loss of control and an accident. Independent use of the front or rear brakes reduces overall braking performance. Extreme braking may cause either wheel to lock, reducing control of the motorcycle and causing an accident.

When possible, reduce speed or brake before entering a turn as closing the throttle or braking in mid-turn may cause wheel slip leading to loss of control and an accident.

When riding in wet or rainy conditions, or on loose surfaces, the ability to manoeuvre and stop will be reduced. All of your actions should be smooth under these conditions. Sudden acceleration, braking or turning may cause loss of control and an accident.

### Warning

When descending a long, steep gradient, use engine braking by down changing and use the brakes intermittently. Continuous brake application can overheat the brakes and reduce their effectiveness.


Riding with your foot on the brake pedal or your hands on the brake lever may actuate the brake light, giving a false indication to other road users. It may also overheat the brake, reducing braking effectiveness.

Do not coast with the engine switched off, and do not tow the motorcycle. The transmission is pressure-lubricated only when the engine is running. Inadequate lubrication may cause damage or seizure of the transmission, which can lead to sudden loss of motorcycle control and an accident.



## How to Ride the Motorcycle

### Parking



Select neutral and turn the ignition switch to the OFF position.

Lock the steering to help prevent theft.

Always park on a firm, level surface to prevent the motorcycle from falling.

When parking on a hill, always park facing uphill to prevent the motorcycle from rolling off the stand. Engage first gear to prevent the motorcycle from moving.

On a lateral (sideways) incline, always park such that the incline naturally pushes the motorcycle towards the sidestand.

Do not park on a lateral (sideways) incline of greater than 6° and never park facing downhill.

#### Note:

- **When parking near traffic at night, or when parking in a location where parking lights are required by law, leave the tail, licence plate and position lights on by turning the ignition switch to P (PARK).**

Do not leave the switch in the P position for long periods of time as this will discharge the battery.

#### Warning

Do not park on a soft or on a steeply inclined surface. Parking under these conditions may cause the motorcycle to fall over causing damage to property and personal injury.

#### Warning

Petrol is extremely flammable and can be explosive under certain conditions. If parking inside a garage or other structure, be sure it is well ventilated and the motorcycle is not close to any source of flame or sparks. This includes any appliance with a pilot light.

Failure to follow the above advice may cause a fire resulting in damage to property or personal injury.

#### Warning

The engine and exhaust system will be hot after riding. DO NOT park where pedestrians and children are likely to touch the motorcycle.

Touching any part of the engine or exhaust system when hot may cause unprotected skin to become burnt.

## How to Ride the Motorcycle

---

### Considerations for High-Speed Operation

#### Warning

This Triumph motorcycle should be operated within the legal speed limits for the particular road travelled. Operating a motorcycle at high speeds can be potentially dangerous since the time available to react to given traffic situations is greatly reduced as road speed increases. Always reduce speed in consideration of weather and traffic conditions.

#### Warning

Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed-course racetracks. High-speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high-speed riding and are familiar with the motorcycle's characteristics in all conditions.

High-speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

#### Warning

The handling characteristics of a motorcycle at high speed may vary from those you are familiar with at legal road speeds. Do not attempt high-speed operation unless you have received sufficient training and have the required skills as a serious accident may result from incorrect operation.

#### Warning

The items listed are extremely important and must never be neglected. A problem, which may not be noticed at normal operating speeds, may be greatly exaggerated at high speeds.

#### **General**

Ensure the motorcycle has been maintained according to the scheduled maintenance chart.

#### **Steering**

Check that the handlebar turns smoothly without excessive free play or tight spots. Ensure that the control cables do not restrict the steering in any way.

#### **Luggage**

Make certain that any luggage containers are closed, locked and securely fitted to the motorcycle.

#### **Brakes**

Check that the front and rear brakes are functioning properly.

## How to Ride the Motorcycle

---

### **Tyres**

High-speed operation is hard on tyres, and tyres that are in good condition are crucial to riding safely. Examine their overall condition, inflate to the correct pressure (when the tyres are cold), and check the wheel balance. Securely fit the valve caps after checking tyre pressures. Observe the information given in the Maintenance and Specification sections on tyre checking and tyre safety.

### **Fuel**

Have sufficient fuel for the increased fuel consumption that will result from high-speed operation.

**Caution**

The exhaust system is fitted with a catalytic converter to help reduce exhaust emission levels. The catalytic converter can be permanently damaged if the motorcycle is allowed to run out of fuel or if the fuel level is allowed to get very low. Always ensure you have adequate fuel for your journey.

### **Engine Oil**

Make certain that the engine oil level is correct. Ensure that the correct grade and type of oil is used when topping up.

### **Coolant**

Check that the coolant level is at the upper level line in the expansion tank. (Always check the level with the engine cold.)

### **Electrical Equipment**

Make certain that the headlight, rear/brake light, direction indicators, horn, etc. all work properly.

### **Miscellaneous**

Visually check that all fixings are tight.

## How to Ride the Motorcycle

---

This page intentionally left blank

## Accessories and Loading

### ACCESSORIES AND LOADING

The addition of accessories and carriage of additional weight can affect the motorcycle's handling characteristics causing changes in stability and necessitating a reduction in speed. The following information has been prepared as a guide to the potential hazards of adding accessories to a motorcycle and carrying passengers and additional loads.

#### Warning

Incorrect loading may result in an unsafe riding condition leading to an accident.

Always ensure any loads carried are evenly distributed on both sides of the motorcycle. Ensure that the load is correctly secured such that it will not move around while the motorcycle is in motion.

Always check the load security regularly (though not while the motorcycle is in motion) and ensure that the load does not extend beyond the rear of the motorcycle.

Never exceed the maximum vehicle loading weight of 195 kg.

This maximum loading weight is made up from the combined weight of the rider, passenger, any accessories fitted and any load carried.

#### Warning

Do not install accessories or carry luggage that impairs the control of the motorcycle. Make sure that you have not adversely affected the visibility of any lighting component, road clearance, banking capability (i.e. lean angle), control operation, wheel travel, front fork movement, visibility in any direction, or any other aspect of the motorcycle's operation.

#### Warning

This motorcycle must not be operated above the legal road speed limit except in authorised closed-course conditions.

#### Warning

Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed-course racetracks. High-speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high-speed riding and are familiar with the motorcycle's characteristics in all conditions.

High-speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

## Accessories and Loading

### Warning

Your passenger should be instructed that he or she can cause loss of motorcycle control by making sudden movements or by adopting an incorrect seated position.

The rider should instruct the passenger as follows:

- It is important that the passenger sits still while the motorcycle is in motion and does not interfere with the operation of the motorcycle.
- To keep his or her feet on the passenger footrests and to firmly hold onto the seat strap or the rider's waist or hips.
- Advise the passenger to lean with the rider when travelling around corners and not to lean unless the rider does so.

### Warning

Do not carry animals on your motorcycle. An animal could make sudden and unpredictable movements that could lead to loss of motorcycle control and an accident.

### Warning


The handling and braking capabilities of a motorcycle will be affected by the presence of a passenger. The rider must make allowances for these changes when operating the motorcycle with a passenger and should not attempt such operation unless trained to do so and without becoming familiar and comfortable with the changes in motorcycle operating characteristics that this brings about.

Motorcycle operation without making allowances for the presence of a passenger could lead to loss of motorcycle control and an accident.

### Warning

Never attempt to store any items between the frame and the fuel tank. This can restrict the steering and will cause loss of control leading to an accident.

Weight attached to the handlebar or front fork will increase the mass of the steering assembly and can result in loss of steering control leading to an accident.



## Accessories and Loading

### Warning

Do not carry a passenger unless he or she is tall enough to reach the footrests provided.

A passenger who is not tall enough to reach the footrests will be unable to sit securely on the motorcycle and may cause instability leading to loss of control and an accident.

### Warning

Never ride an accessory equipped motorcycle, or a motorcycle carrying a payload of any kind, at speeds above 80 mph (130 km/h). In either/both of these conditions, speeds in excess of 80 mph (130 km/h) should not be attempted even where the legal speed limit permits this.

The presence of accessories and/or payload will cause changes in the stability and handling of the motorcycle.

Failure to allow for changes in motorcycle stability may lead to loss of control or an accident.

Remember that the 80 mph (130 km/h) absolute limit will be reduced by the fitting of non-approved accessories, incorrect loading, worn tyres, overall motorcycle condition and poor road or weather conditions.

### Warning

If the passenger seat is used to carry small objects, they must not exceed 5 kg in weight, must not impair control of the motorcycle, must be securely attached and must not extend beyond the rear or sides of the motorcycle.

Carriage of objects in excess of 5 kg in weight, that are insecure, impair control or extend beyond the rear or sides of the motorcycle may lead to loss of motorcycle control and an accident.

Even if small objects are correctly loaded onto the rear seat, the maximum speed of the motorcycle must be reduced to 80 mph (130 km/h).

### Caution

Do not allow luggage to rest on or against the upper portion of the rear bodywork.

Allowing luggage to rest on or against the upper portion of the rear bodywork could close the air gap between the bodywork and the exhaust potentially causing the bodywork to become damaged by overheating.

## Accessories and Loading

---

This page intentionally left blank



## Maintenance and Adjustment

---

### MAINTENANCE AND ADJUSTMENT

#### Table of Contents

Scheduled Maintenance . . . . .	68
Engine Oil . . . . .	71
Oil Level Inspection . . . . .	71
Oil and Oil Filter Change . . . . .	72
Disposal of Used Engine Oil and Oil Filters . . . . .	74
Oil Specification and Grade . . . . .	74
Cooling System . . . . .	74
Corrosion Inhibitors . . . . .	74
Coolant Level Inspection . . . . .	75
Coolant Level Adjustment . . . . .	76
Coolant Change . . . . .	77
Radiator and Hoses . . . . .	77
Throttle Control . . . . .	77
Inspection . . . . .	78
Adjustment . . . . .	78
Clutch . . . . .	80
Inspection . . . . .	80
Adjustment . . . . .	80
Drive Chain . . . . .	81
Chain Lubrication . . . . .	81
Chain Free-Movement Inspection . . . . .	82
Chain Free-Movement Adjustment . . . . .	82
Chain and Sprocket Wear Inspection . . . . .	83
Brakes . . . . .	84
Brake Wear Inspection . . . . .	84
Brake Pad Wear Compensation . . . . .	85
Disc Brake Fluid . . . . .	85
Front Brake Fluid Level Inspection and Adjustment - Daytona 675 . . . . .	86
Front Brake Fluid Level Inspection and Adjustment - Street Triple . . . . .	86
Rear Brake Fluid Inspection and Adjustment . . . . .	87
Brake Light Switches . . . . .	87

## Maintenance and Adjustment

---

Windscreen Cleaning .....	88
Steering/Wheel Bearings .....	89
Steering Inspection .....	89
Inspecting the Steering (Headstock) Bearings for Free Play .....	89
Wheel Bearings Inspection .....	90
Front Suspension .....	90
Front Fork Inspection .....	90
Suspension Setting Chart - Daytona 675 only .....	91
Front Suspension Settings .....	92
Spring Pre-Load Adjustment .....	92
Rebound Damping Adjustment .....	92
Compression Damping Adjustment .....	93
Rear Suspension Adjustment .....	93
Rebound Damping Adjustment .....	93
Compression Damping Adjustment .....	94
Tyres .....	94
Tyre Inflation Pressures .....	95
Tyre Wear .....	95
Minimum Recommended Tread Depth .....	95
Tyre Replacement .....	96
Battery .....	98
Battery Removal .....	99
Battery Disposal .....	99
Battery Maintenance .....	99
Battery Discharge .....	100
Battery Maintenance During Motorcycle Storage .....	100
Battery Charging .....	100
Battery Installation .....	101
Fuse Box .....	101
Fuse Identification .....	103
Headlights .....	104
Headlights .....	104
Headlight Adjustment - Daytona 675 .....	104
Headlight Adjustment - Street Triple .....	105
Headlight Bulb Replacement - Daytona 675 .....	106

## Maintenance and Adjustment

---

Headlight Bulb Replacement - Street Triple .....	107
Rear Light .....	108
Rear Light Replacement - Both Models .....	108
Direction Indicator Lights .....	108
Bulb Replacement - Daytona 675 .....	108
Bulb Replacement - Street Triple .....	109
Licence Plate Light .....	109
Bulb Replacement - Both Models .....	109
Cleaning .....	110
Preparation for Washing .....	110
Where to be Careful .....	111
After Washing .....	111
Unpainted Aluminium Items .....	111
Cleaning of the Exhaust System .....	112
Washing .....	112
Drying .....	112
Protecting .....	112

## Maintenance and Adjustment

---

### Scheduled Maintenance

To maintain the motorcycle in a safe and reliable condition, the maintenance and adjustments outlined in this section must be carried out as specified in the schedule of daily checks, and also in line with the scheduled maintenance chart. The information that follows describes the procedures to follow when carrying out the daily checks and some simple maintenance and adjustment items.

#### Warning

Special tools, knowledge and training are required in order to correctly carry out the maintenance items listed in the scheduled maintenance chart. Only an authorised Triumph dealer will have this knowledge and equipment.

Since incorrect or neglected maintenance can lead to a dangerous riding condition, always have an authorised Triumph dealer carry out the scheduled maintenance of this motorcycle.

#### Warning

All maintenance is vitally important and must not be neglected. Incorrect maintenance or adjustment may cause one or more parts of the motorcycle to malfunction. A malfunctioning motorcycle may lead to loss of control and an accident.

Weather, terrain and geographical location affects maintenance. The maintenance schedule should be adjusted to match the particular environment in which the vehicle is used and the demands of the individual owner.

Since incorrect or neglected maintenance can lead to a dangerous riding condition, always have an authorised Triumph dealer carry out the scheduled maintenance of this motorcycle.

Triumph Motorcycles cannot accept any responsibility for damage or injury resulting from incorrect maintenance or improper adjustment carried out by the owner.

## Maintenance and Adjustment

Operation Description	Odometer Reading in Miles (Kms) or Time Period, whichever comes first						
		First Service	A Service	B Service	C Service	D Service	A Service
	Every	500 (800) 1 month	6,000 (10,000) 1 year	12,000 (20,000) 2 years	18,000 (30,000) 3 years	24,000 (40,000) 4 years	30,000 (50,000) 5 years
Engine oil cooler - check for leaks	Day	•	•	•	•	•	•
Engine oil - renew	-	•	•	•	•	•	•
Engine and oil filter - renew	-	•	•	•	•	•	•
Valve clearances - check/adjust	-			•		•	
Air cleaner - renew	-			•		•	
Engine ECM - check for stored DTCs	-	•	•	•	•	•	•
Spark plugs - check	-		•		•		•
Spark plugs - renew	-			•		•	
Throttle bodies - balance	-		•	•	•	•	•
Throttle cables - check/adjust	Day	•	•	•	•	•	•
Cooling system - check for leaks	Day	•	•	•	•	•	•
Coolant level - check/adjust	Day	•	•		•		•
Coolant - renew	-			•		•	
Fuel system - check for leaks, chafing etc.	Day	•	•	•	•	•	•
Lights, instruments and electrical systems - check	Day	•	•	•	•	•	•
Steering - check for free operation	Day	•	•	•	•	•	•
Headstock bearings - check/adjust	-		•	•	•	•	•
Headstock bearings - lubricate	-			•		•	
Forks - check for leaks/smooth operation	Day	•	•	•	•	•	•
Fork oil - renew	-						•

## Maintenance and Adjustment

Operation Description	Odometer Reading in Miles (Kms) or Time Period, whichever comes first						
		First Service	A Service	B Service	C Service	D Service	A Service
	Every	500 (800) 1 month	6,000 (10,000) 1 year	12,000 (20,000) 2 years	18,000 (30,000) 3 years	24,000 (40,000) 4 years	30,000 (50,000) 5 years
Brake fluid levels - check	Day	•	•	•	•	•	•
Brake fluid - renew	Every 2 years						
Brake pad - check wear levels	Day	•	•	•	•	•	•
Brake master cylinders - check for fluid leaks	Day	•	•	•	•	•	•
Brake calipers - check for fluid leaks and seized pistons	Day	•	•	•	•	•	•
Drive chain - lubricate	Every 200 miles (300 kms)						
Drive chain - wear check	Every 500 miles (800 kms)						
Drive chain slack - check/adjust	Day	•	•	•	•	•	•
Drive chain rubbing strip - check	-		•	•	•	•	•
Fasteners - inspect visually for security	Day	•	•	•	•	•	•
Wheels - inspect for damage	Day	•	•	•	•	•	•
Tyre wear/tyre damage - check	Day	•	•	•	•	•	•
Tyre pressures - check/adjust	Day	•	•	•	•	•	•
Clutch cable - check/adjust	Day	•	•	•	•	•	•
Secondary air injection system - check/clean	-			•		•	
Stand - check operation	Day	•	•	•	•	•	•
Exhaust butterfly valve cables - check/adjust (Daytona 675 only)	-		•	•	•	•	•
Secondary exhaust clamp bolts - check/adjust	-	•	•	•	•	•	•
Fuel and evaporative loss* hoses - renew	-					•	

\*Evaporative system fitted to California models only.

## Maintenance and Adjustment

### Engine Oil




In order for the engine, transmission, and clutch to function correctly, maintain the engine oil at the correct level, and change the oil and oil filter in accordance with scheduled maintenance requirements.

#### Warning

Motorcycle operation with insufficient, deteriorated, or contaminated engine oil will cause accelerated engine wear and may result in engine or transmission seizure. Seizure of the engine or transmission may lead to sudden loss of control and an accident.

### Oil Level Inspection



1. Filler
2. Dipstick location in crankcase
3. Dipstick
4. Upper marking
5. Lower marking

#### Warning

Never start the engine or run the engine in a confined area. Exhaust fumes are poisonous and can cause loss of consciousness and death within a short period of time. Always operate your motorcycle in the open-air or in an area with adequate ventilation.

#### Caution

Running the engine with insufficient oil will cause engine damage. If the low oil pressure indicator remains on, stop the engine immediately and investigate the cause.

## Maintenance and Adjustment

Start the engine and run at idle for approximately five minutes.

Stop the engine, then wait for at least three minutes for the oil to settle.

Remove the dipstick, wipe the blade clean and screw fully home.

### Note:

- **An accurate indication of the level of oil in the engine is only shown when the engine is at normal operating temperature, the motorcycle is upright (not on the side stand) and when the dipstick has been screwed fully home.**
- **Do not add oil through the dipstick hole in the crankcase.**


Remove the dipstick.

The oil level is indicated by lines on the dipstick. When full, the indicated oil level must be level with the upper marking on the dipstick.

If the oil level is below the lower marking, remove the filler plug and add oil a little at a time through the filler plug hole in the clutch cover until the correct level is reached.

Once the correct level is reached, fit the dipstick and the filler plug.

### Oil and Oil Filter Change



1. Oil drain plug
2. Oil filter

The engine oil and filter must be replaced in accordance with scheduled maintenance requirements.

### Warning

Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis. In addition, used engine oil contains harmful contamination that can lead to skin cancer. Always wear suitable protective clothing and avoid skin contact with used oil.

Warm up the engine thoroughly, and then stop the engine and secure the motorcycle in an upright position on level ground.

Remove the lower fairing (Daytona 675 only).

Place an oil drain pan beneath the engine.

Remove the oil drain plug.



## Maintenance and Adjustment

---

### Warning

The oil may be hot to the touch. Avoid contact with the hot oil by wearing suitable protective clothing, gloves, eye protection, etc. Contact with hot oil may cause the skin to be scalded or burned.

Unscrew and remove the oil filter using Triumph service tool T3880313. Dispose of the old filter in an environmentally friendly way.

Apply a thin smear of clean engine oil to the sealing ring of the new oil filter. Fit the oil filter and tighten to **10 Nm**.

Refit the oil drain plug and tighten to **25 Nm**.

Fill the engine with a 10W/40 or 15W/50 semi or fully synthetic motorcycle engine oil that meets specification API SH (or higher) AND JASO MA.

Start the engine and allow it to idle for a minimum of 30 seconds.

### Caution

If the engine oil pressure is too low, the low oil pressure warning light will illuminate. If this light stays on when the engine is running, stop the engine immediately and investigate the cause. Running the engine with low oil pressure will cause engine damage.

Ensure that the low oil pressure warning light extinguishes shortly after starting.

Turn off the ignition, check the oil level using the method previously described, and top up to between the minimum and maximum level lines on the dipstick.

Refit the lower fairing (Daytona 675 only).

### Caution

Raising the engine speed above idle before the oil reaches all parts of the engine can cause engine damage or seizure. Only raise engine speed after running the engine for 30 seconds to allow the oil to circulate fully.

## Maintenance and Adjustment

---

### Disposal of Used Engine Oil and Oil Filters

To protect the environment, do not pour oil on the ground, down sewers or drains, or into watercourses. Do not place used oil filters in with general waste. If in doubt, contact your local authority.


### Oil Specification and Grade

Triumph high performance fuel injected engines are designed to use 10W/40 or 15W/50 semi or fully synthetic motorcycle engine oil that meets specification API SH (or higher) AND JASO MA.

Do not add any chemical additives to the engine oil. The engine oil also lubricates the clutch and any additives could cause the clutch to slip.

Do not use mineral, vegetable, non-detergent oil, castor based oils or any oil not conforming to the required specification. The use of these oils may cause instant, severe engine damage.

### Cooling System



To ensure efficient engine cooling, check the coolant level each day before riding the motorcycle, and top up the coolant if the level is low.

#### **Caution**

A year-round type of anti-freeze is installed in the cooling system when the motorcycle leaves the factory. It is coloured green, contains a 50% solution of ethylene glycol, and has a freezing point of  $-35^{\circ}\text{C}$  ( $-31^{\circ}\text{F}$ ).

### Corrosion Inhibitors

To protect the cooling system from corrosion, the use of corrosion inhibitor chemicals in the coolant is essential.

If coolant containing a corrosion inhibitor is not used, the cooling system will accumulate rust and scale in the water jacket and radiator. This will block the coolant passages, and considerably reduce the efficiency of the cooling system.

The anti-freeze recommended in the Specification section, mixed 50/50 with distilled water will provide the necessary corrosion inhibition.

## Maintenance and Adjustment

### Warning

Always use the anti-freeze in accordance with the instructions of the manufacturer.

Coolant mixture that contains anti-freeze and corrosion inhibitors contains toxic chemicals that are harmful to the human body. Never swallow anti-freeze or any of the motorcycle coolant.

Distilled water must be used to dilute coolant to the correct mixture ratio.


In an emergency, tap water can be added to the cooling system. However, the coolant must then be changed and returned to the correct mixture ratio using distilled water and new coolant as soon as possible.

### Caution

Distilled water must be used to dilute coolant to the correct mixture ratio. If hard water is used in the cooling system, it will cause scale accumulation in the engine and radiator and considerably reduce the efficiency of the cooling system. Reduced cooling system efficiency may cause the engine to overheat and suffer severe damage.

### Coolant Level Inspection

#### Daytona 675



1. Expansion tank
2. Tank cap
3. MAX mark
4. MIN mark

#### Note:


- **The coolant level should be checked when the engine is cold (at room or ambient temperature).**

Position the motorcycle on level ground and in an upright position. The expansion tank can be viewed from the left hand of the motorcycle, between the rear of the lower fairing and the frame.

Check the coolant level in the expansion tank. The coolant level must be between the MAX and MIN marks. If the coolant is below the minimum level, the coolant level must be adjusted.

## Maintenance and Adjustment

### Street Triple



1. Expansion tank
2. Tank cap
3. MAX mark
4. MIN mark

#### Note:

- **The coolant level should be checked when the engine is cold (at room or ambient temperature).**

Position the motorcycle on level ground and in an upright position.

Remove the seat. The expansion tank is positioned between the frame rails beneath the seat.

Check the coolant level in the expansion tank. The coolant level must be between the MAX and MIN marks. If the coolant is below the minimum level, the coolant level must be adjusted.

### Coolant Level Adjustment

#### Warning

Do not remove the expansion tank or radiator pressure cap when the engine is hot. When the engine is hot, the coolant inside the expansion tank will be hot and also under pressure. Contact with this hot, pressurised coolant will cause scalds and skin damage.

Allow the engine to cool.

#### Daytona 675

The expansion tank cap can be removed from the left hand of the motorcycle, between the rear of the lower fairing and the frame.

#### Street Triple

Remove the seat to gain access to the expansion tank.

Remove the cap from the expansion tank and add coolant mixture through the filler opening until the level reaches the MAX mark. Refit the cap.

#### Note:

- **If the coolant level is being checked because the coolant has overheated, also check the level in the radiator and top up if necessary.**
- **In an emergency, water alone can be added to the cooling system. However, the coolant must then be changed and returned to the correct mixture ratio using distilled water and new coolant as soon as possible.**

## Maintenance and Adjustment

### Coolant Change

Have the coolant changed by an authorised Triumph dealer in accordance with scheduled maintenance requirements.

### Radiator and Hoses

Check the radiator hoses for cracks or deterioration, and hose clips for tightness in accordance with scheduled maintenance requirements. Have your authorised Triumph dealer replace any defective items.

Check the radiator grille and fins for obstructions by insects, leaves or mud. Clean off any obstructions with a stream of low-pressure water.

#### Warning


The fan operates automatically when the engine is running. Always keep hands and clothing away from the fan as contact with the rotating fan can cause injury.

#### Caution

Using high-pressure water sprays, such as from a car wash facility or household pressure washer, can damage the radiator fins, cause leaks and impair the radiator's efficiency.

Do not obstruct or deflect airflow through the radiator by installing unauthorised accessories, either in front of the radiator or behind the cooling fan. Interference with the radiator airflow can cause overheating, potentially resulting in engine damage.

### Throttle Control



1. Throttle grip (Daytona 675 shown)
2. Correct setting 2 - 3 mm

#### Warning

The throttle grip controls the throttle valves in the throttle bodies. If the throttle cables are incorrectly adjusted, either too tight or too loose, the throttle may be difficult to control and performance will be adversely affected.

Check the throttle grip free play in accordance with scheduled maintenance requirements and make adjustments as necessary.

## Maintenance and Adjustment

### Warning

Always be alert for changes in the 'feel' of the throttle and have the throttle system checked by an authorised Triumph dealer if any changes are detected. Changes can be due to wear in the mechanism, which could lead to a sticking throttle.

An incorrectly adjusted, sticking or stuck throttle will lead to loss of motorcycle control and an accident.

### Inspection

### Warning

Use of the motorcycle with incorrectly adjusted, incorrectly routed, sticking or damaged throttle cables will interfere with the throttle function resulting in loss of motorcycle control and an accident.


To avoid incorrect adjustment, incorrect routing, or continued use of a sticking or damaged throttle, always have your throttle checked and adjusted by your authorised Triumph dealer.

Check that the throttle opens smoothly, without undue force and that it closes without sticking. Have your authorised Triumph dealer check the throttle system if a problem is detected or any doubt exists.

Check that there is 2 - 3 mm of throttle grip free play when lightly turning the throttle grip back and forth.

If there is an incorrect amount of free play, Triumph recommends that you have adjustments made by your authorised Triumph dealer. However, in an emergency, throttle adjustment may be made as follows:

### Adjustment



1. Opening cable adjuster
2. Closing cable adjuster
3. Closing cable – free play measurement point
4. Throttle grip (Daytona 675 shown)
5. Opening cable – free play measurement point

## Maintenance and Adjustment

---

Remove the seat.

Disconnect the battery, negative (black) lead first.

Remove the fuel tank.

Remove the airbox.

Release the locknuts on the 'opening' cable adjusters.

Rotate the 'opening' cable adjuster at the throttle grip end such that it has an equal amount of adjustment in each direction.

Rotate the 'opening' cable adjuster at the throttle body end of the cable to give 2 - 3 mm of play at the throttle grip. Tighten the locknut.

Make any minor adjustments as necessary to give 2 - 3 mm of play using the adjuster near the throttle grip end of the cable. Tighten the adjuster locknut.

With the throttle fully closed, ensure that there is 2 - 3 mm of free play in the 'closing' cable at the throttle cam attached to the throttle bodies. If necessary, adjust at the throttle body end in the same way as the 'opening' cable, until 2 - 3 mm of play is present.

Tighten the adjuster locknuts.

### **Warning**

Ensure that all the adjuster locknuts of all cables are tightened, as a loose locknut could result in a sticking throttle.

An incorrectly adjusted, sticking or stuck throttle can lead to loss of motorcycle control and an accident.

Refit the airbox.

Refit the fuel tank.

Reconnect the battery, positive (red) lead first.

Refit the seat.


Check that the throttle opens smoothly, without undue force and that it closes without sticking.

Ride carefully to your nearest authorised Triumph dealer and have him check the throttle system thoroughly before riding again.

## Maintenance and Adjustment

---

### Clutch



- 1. Clutch lever
- 2. 2 - 3 mm

The motorcycle is equipped with a cable-operated clutch.

If the clutch lever has excessive free play, the clutch may not disengage fully. This will cause difficulty in changing gear and selecting neutral. This may cause the engine to stall and make the motorcycle difficult to control.

Conversely, if the clutch lever has insufficient free play the clutch may not engage fully, causing the clutch to slip, which will reduce performance and cause premature clutch wear.

Clutch lever free play must be checked in accordance with scheduled maintenance requirements.

### Inspection

Check that there is 2 - 3 mm clutch lever free play at the lever.

If there is an incorrect amount of free play, adjustments must be made.

### Adjustment

Loosen the knurled locknut at the lever end of the clutch cable and turn the adjuster sleeve until the correct amount of clutch lever free play is achieved.

Tighten the knurled locknut against the clutch lever assembly.

If correct adjustment cannot be made using the lever adjuster, use the cable adjuster at the lower end of the cable.

Loosen the adjuster locknut.

Turn the outer cable adjuster to give 2 - 3 mm of free play at the clutch lever.

Tighten the locknut.



## Maintenance and Adjustment

### Drive Chain



For safety and to prevent excessive wear the drive chain must be checked, adjusted and lubricated in accordance with scheduled maintenance requirements. Checking, adjustment and lubrication must be carried out more frequently for extreme conditions such as salty or heavily gritted roads.

If the chain is badly worn or incorrectly adjusted (either too loose or too tight) the chain could jump off the sprockets or break. Therefore, always replace worn or damaged chains using genuine Triumph parts supplied by an authorised Triumph dealer.

#### **Warning**

A loose or worn chain, or a chain that breaks or jumps off the sprockets could catch on the engine sprocket or lock the rear wheel.

A chain that snags on the engine sprocket will injure the rider and lead to loss of motorcycle control and an accident.

Similarly, locking the rear wheel will lead to loss of motorcycle control and an accident.

### Chain Lubrication

Lubrication is necessary every 200 miles (300 kms) and also after riding in wet weather, on wet roads, or any time that the chain appears dry.

Use the special chain lubricant as recommended in the Specification section.

Apply lubricant to the sides of the rollers then allow the motorcycle to stand unused for at least 8 hours (overnight is ideal). This will allow the oil to penetrate to the chain O-rings etc.

Before riding, wipe off any excess oil.


If the chain is especially dirty, clean first and then apply oil as mentioned above.

#### **Caution**

Do not use a pressure wash to clean the chain as this may cause damage to the chain components.

## Maintenance and Adjustment

### Chain Free-Movement Inspection



1. Maximum movement position

#### Warning

Before starting work, ensure the motorcycle is stabilised and adequately supported. This will help prevent injury to the operator or damage to the motorcycle.


Place the motorcycle on a level surface and hold it in an upright position with no weight on it.

Rotate the rear wheel by pushing the motorcycle to find the position where the chain is tightest, and measure the vertical movement of the chain midway between the sprockets.

### Chain Free-Movement Adjustment

For Daytona 675, the vertical movement of the drive chain must be in the range 35 - 40 mm.

For Street Triple, the vertical movement of the drive chain must be in the range 20 - 25 mm.



1. Adjuster bolt
2. Adjuster bolt locknut
3. Rear wheel spindle nut

Loosen the wheel spindle nut.

Release the locknuts on both the left hand and right hand chain adjuster bolts.

Moving both adjusters by an equal amount, turn the adjuster bolts clockwise to increase chain free-movement and counter clockwise to reduce chain free-movement.

When the correct amount of chain free-movement has been set, push the wheel into firm contact with the adjuster. Tighten both adjuster locknuts to **27 Nm** and the rear wheel spindle nut to **110 Nm**.

Repeat the chain adjustment check. Re-adjust if necessary.

## Maintenance and Adjustment

### Warning


Operation of the motorcycle with insecure adjuster locknuts or a loose wheel spindle may result in impaired stability and handling of the motorcycle. This impaired stability and handling may lead to loss of control or an accident.

Check the rear brake effectiveness. Rectify if necessary.

### Warning

It is dangerous to operate the motorcycle with defective brakes and you must have your authorised Triumph dealer take remedial action before you attempt to ride the motorcycle again. Failure to take remedial action may reduce braking efficiency leading to loss of control or an accident.

### Chain and Sprocket Wear Inspection



1. Measure across 20 links
2. Weight

Remove the chain guard.


Stretch the chain taut by hanging a 10 - 20 kg weight on the chain.

Measure the length of 20 links on the straight part of the chain from pin centre of the 1<sup>st</sup> pin to the pin centre of the 21<sup>st</sup> pin. Since the chain may wear unevenly, take measurements in several places.

If the length exceeds the maximum service limit of 319 mm, the chain must be replaced.

Rotate the rear wheel and inspect the drive chain for damaged rollers, and loose pins and links.

Also inspect the sprockets for unevenly or excessively worn or damaged teeth.



If there is any irregularity, have the drive chain and/or the sprockets replaced by an authorised Triumph dealer.

Replace the chain guard.

## Maintenance and Adjustment

---

### Warning

The use of non-approved chains may result in a broken chain or may cause the chain to jump off the sprockets.

Use a genuine Triumph supplied chain as specified in the Triumph Parts Catalogue.

Never neglect chain maintenance and always have chains installed by an authorised Triumph dealer.


### Caution

If the sprockets are found to be worn, always replace the sprockets and drive chain together.

Replacing worn sprockets without also replacing the chain will lead to premature wear of the new sprockets.

## Brakes

### Brake Wear Inspection



#### 1. Brake pads

#### 2. Minimum thickness line

Brake pads must be inspected in accordance with scheduled requirements and replaced if worn to, or beyond the minimum service thickness.

If the lining thickness of any pad (front or rear brakes) is less than 1.5 mm (0.06 in), that is, if the pad has worn down to the bottom of the grooves, replace all the pads on the wheel.

## Maintenance and Adjustment

### Warning

Brake pads must always be replaced as a wheel set. At the front, where two calipers are fitted on the same wheel, replace all the brake pads in both calipers.

Replacing individual pads will reduce braking efficiency and may cause an accident.

After replacement brake pads have been fitted, ride with extreme caution until the new pads have 'broken in'.

### Brake Pad Wear Compensation

Disc and brake pad wear is automatically compensated for and has no effect on the brake lever or pedal action. There are no parts that require adjustment on the front and rear brakes.

### Warning

If the brake lever or pedal feels soft when it is applied, or if the lever/pedal travel becomes excessive, there may be air in the brake pipes and hoses or the brakes may be defective.

It is dangerous to operate the motorcycle under such conditions and your authorised Triumph dealer must rectify the fault before riding.

Riding with defective brakes may lead to loss of motorcycle control and an accident.

### Disc Brake Fluid

Inspect the level of brake fluid in both reservoirs and change the brake fluid in accordance with scheduled maintenance requirements. Use only DOT 4 fluid as recommended in the Specification section. The brake fluid must also be changed if it becomes, or is suspected of having become contaminated with moisture or any other contaminants.

### Warning

Brake fluid is hygroscopic which means it will absorb moisture from the air.

Any absorbed moisture will greatly reduce the boiling point of the brake fluid causing a reduction in braking efficiency.

Because of this, always replace brake fluid in accordance with scheduled maintenance requirements.

Always use new brake fluid from a sealed container and never use fluid from an unsealed container or from one which has been previously opened.

Do not mix different brands or grades of brake fluid.


Check for fluid leakage around brake fittings, seals and joints and also check the brake hoses for splits, deterioration and damage.

Always rectify any faults before riding.

Failure to observe and act upon any of these items may cause a dangerous riding condition leading to loss of control and an accident.

## Maintenance and Adjustment

### Front Brake Fluid Level Inspection and Adjustment - Daytona 675



1. Front brake fluid reservoir, upper level line
2. Lower level line
3. Safety clip

The brake fluid level in the reservoirs must be kept between the upper and lower level lines (reservoir held horizontal).

Remove the safety clip.


Remove the reservoir cover.

Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.

Refit the reservoir cover ensuring that the diaphragm seal is correctly fitted.

Refit the safety clip.

### Front Brake Fluid Level Inspection and Adjustment - Street Triple



1. Front brake fluid reservoir, upper level line
2. Lower level line

The brake fluid level in the reservoirs must be kept between the upper and lower level lines (reservoir held horizontal).

To inspect the fluid level, check the level of fluid visible in the window at the front of the reservoir body.

To adjust the fluid level, release the cap screws and detach the cover noting the position of the sealing diaphragm.


Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.

Refit the cover, ensuring that the diaphragm seal is correctly positioned between the cap and reservoir body. Tighten the cap retaining screws.

## Maintenance and Adjustment

### Rear Brake Fluid Inspection and Adjustment

Both Models



1. Rear brake fluid reservoir, upper level line
2. Lower level line

### Brake Light Switches

The brake light is activated independently by either the front or rear brake. If, with the ignition in the ON position, the brake light does not work when the front brake lever is pulled or the rear brake pedal is pressed, have your authorised Triumph dealer investigate and rectify the fault.

#### Warning

Riding the motorcycle with defective brake lights is illegal and dangerous.

An accident causing injury to the rider and other road users may result from use of a motorcycle with defective brake lights.

#### Warning

If there has been an appreciable drop in the level of the fluid in either fluid reservoir, consult your authorised Triumph dealer for advice before riding. Riding with depleted brake fluid levels, or with a brake fluid leak is dangerous and will cause reduced brake performance potentially leading to loss of motorcycle control and an accident.

## Maintenance and Adjustment

---

### Windscreen Cleaning

Daytona 675 only



Clean the windscreen with a solution of mild soap or detergent and lukewarm water. After cleaning, rinse well and then dry with a soft, lint free cloth.

#### Caution

Products such as window cleaning fluids, insect remover, rain repellent, scouring compounds, petrol or strong solvents such as alcohol, acetone, carbon tetrachloride, etc. will damage the windscreen. Never allow these products to contact the screen.

If the transparency of the windscreen is reduced by scratches or oxidation which cannot be removed, the windscreen must be replaced.

#### Warning

Never attempt to clean the windscreen while the motorcycle is in motion as releasing the handlebars may cause loss of vehicle control and an accident.

Operation of the motorcycle with a damaged or scratched windscreen will reduce the rider's forward vision. Any such reduction in forward vision is dangerous and may lead to an accident causing injury or death.

#### Caution

Corrosive chemicals such as battery acid will damage the windscreen. Never allow corrosive chemicals to contact the windscreen.



## Maintenance and Adjustment

### Steering/Wheel Bearings

#### Caution

To prevent risk of injury from the motorcycle falling during the inspection, ensure that the motorcycle is stabilised and secured on a suitable support. Do not exert extreme force against each wheel or rock each wheel vigorously as this may cause the motorcycle to become unstable and cause injury by falling from its support. Ensure that the position of the support block will not cause damage to the sump.


#### Steering Inspection

Lubricate and inspect the condition of the steering (headstock) bearings in accordance with scheduled maintenance requirements.

#### Note:

- **Always inspect the wheel bearings at the same time as the steering bearings.**

### Inspecting the Steering (Headstock) Bearings for Free Play



#### Inspecting the Steering for Free Play (Daytona 675 shown)

#### Inspection

Position the motorcycle on level ground, in an upright position.

Raise the front wheel above the ground and support the motorcycle.

Standing at the front of the motorcycle, hold the lower end of the front forks and try to move them forward and backward.

If any free play can be detected in the steering (headstock) bearings, ask your authorised Triumph dealer to inspect and rectify any faults before riding.

#### Warning

Riding the motorcycle with incorrectly adjusted or defective steering (headstock) bearings is dangerous and may cause loss of motorcycle control and an accident.

Remove the support and place the motorcycle on the side stand.

## Maintenance and Adjustment

---

### Wheel Bearings Inspection

If the wheel bearings in the front or rear wheel allow play in the wheel hub, are noisy, or if the wheel does not turn smoothly, have your authorised Triumph dealer inspect the wheel bearings.

The wheel bearings must be inspected at the intervals specified in the scheduled maintenance chart.

Position the motorcycle on level ground, in an upright position.

Raise the front wheel above the ground and support the motorcycle.

Standing at the side of the motorcycle, gently rock the top of the front wheel from side to side.

If any free play can be detected, ask your authorised Triumph dealer to inspect and rectify any faults before riding.

Reposition the lifting device and repeat the procedure for the rear wheel.

#### **Warning**

Operation with worn or damaged front or rear wheel bearings is dangerous and may cause impaired handling and instability leading to an accident. If in doubt, have the motorcycle inspected by an authorised Triumph dealer before riding.

Remove the support and place the motorcycle on the side stand.

### Front Suspension

#### Front Fork Inspection

Examine each fork for any sign of damage, scratching of the slider surface, or for oil leaks.

If any damage or leakage is found, consult an authorised Triumph dealer.

To check that the forks operate smoothly:

- Position the motorcycle on level ground.
- While holding the handlebars and applying the front brake, pump the forks up and down several times.
- If roughness or excessive stiffness is detected, consult your authorised Triumph dealer.
- The suspension movement will be affected by adjustment settings (Daytona 675 only).

#### **Warning**

Riding the motorcycle with defective or damaged suspension is dangerous and may lead to loss of control and an accident.

#### **Warning**

Never attempt to dismantle any part of the suspension units, as all units contain pressurised oil. Skin and eye damage can result from contact with the pressurised oil.

## Maintenance and Adjustment

### Suspension Setting Chart - Daytona 675 only

**Note:**

- **The Street Triple model has no front suspension adjustment.**

LOADING		FRONT			REAR	
		Spring Pre-Load*	Rebound Damping*	Compression Damping*	Rebound Damping*	Compression Damping*
Solo Riding	Standard	5	6	7	6	11
	Softer	6	7	8	7	12
	Firmer	4	5	6	5	10
Rider and Passenger		4	5	6	5	10

\* Number of adjuster turns out from the fully screwed in position.

**Note:**

- **This chart is only a guide. Setting requirements may vary for rider weight and personal preferences. See the following pages for information regarding suspension adjustment.**

The standard suspension settings provide a comfortable ride and good handling characteristics for general, solo riding. The chart shows suggested settings for the front and rear suspension.

**Warning**

Ensure that the adjusters are set to the same setting on both forks. Settings which vary from left to right could significantly change handling characteristics leading to loss of control and an accident.

**Warning**


Ensure that the correct balance between front and rear suspension is maintained. Suspension imbalance could significantly change handling characteristics leading to loss of control and an accident. Refer to the chart above for further information or consult your dealer.

## Maintenance and Adjustment

---

### Front Suspension Settings

**Daytona 675 only**



1. Spring pre-load adjuster
2. Rebound damping force adjuster

### Spring Pre-Load Adjustment

The spring pre-load adjusters are located at the top of each fork.

To change the spring pre-load, rotate the adjuster clockwise to increase pre-load, or anti-clockwise to decrease pre-load. Always set the pre-load adjusters such that there are an equal number of graduation lines visible on both forks.

#### Note:

- **The motorcycle is delivered from the factory with the spring pre-load set at position 5.**

### Rebound Damping Adjustment

The rebound damping adjusters are located at the top of each fork.

To change the rebound damping force, rotate the slotted adjuster clockwise to increase, or anti-clockwise to decrease. Always count the turns out from the screwed fully in position and set both forks to the same setting.


#### Note:

- **The motorcycle is delivered from the factory with the rebound set at position 6.**

## Maintenance and Adjustment

### Compression Damping Adjustment

The compression damping adjuster is located near the bottom of both forks, adjacent to the wheel spindle.



#### 1. Compression damping force adjuster

To change the compression damping force, rotate the slotted adjuster clockwise to increase, or anti-clockwise to decrease. Always count the number of turns out from the fully screwed in position and set both forks to the same setting.

#### Note:

- **The motorcycle is delivered from the factory with the compression damping set at position 7.**

### Rear Suspension Adjustment


#### Note:

- **The Street Triple model has no rear suspension adjustment.**

#### Daytona 675 only

The rear suspension unit is adjustable for both rebound and compression damping.

### Rebound Damping Adjustment



#### 1. Rebound damping adjuster

The rebound damping adjuster is located at the bottom of the rear suspension unit on the left hand side of the motorcycle.


To adjust the rebound damping setting, rotate the adjuster clockwise to increase rebound damping and anti-clockwise to decrease.

#### Note:

- **The motorcycle is delivered from the factory with the rebound adjuster set at position 6.**

## Maintenance and Adjustment

### Compression Damping Adjustment



#### 1. Compression damping adjuster

The compression damping adjuster is situated adjacent to the rear suspension unit reservoir.

To adjust the compression damping setting rotate the slotted adjuster clockwise to increase, or anti-clockwise to decrease.

#### Note:


- **The motorcycle is delivered from the factory with the compression damping set at position 11.**

#### Warning

The rear suspension unit spring pre-load is not rider adjustable.

Any attempt to adjust the spring pre-load could result in a dangerous riding condition leading to loss of control and an accident.

### Tyres



#### Tyre Marking




This motorcycle is equipped with tubeless tyres, valves and wheel rims. Use only tyres marked 'TUBELESS' and tubeless valves on rims marked 'SUITABLE FOR TUBELESS TYRES'.

## Maintenance and Adjustment

### Tyre Inflation Pressures

Correct inflation pressure will provide maximum stability, rider comfort and tyre life. Always check tyre pressures before riding when the tyres are cold. Check tyre pressures daily and adjust if necessary. See the Specification section for details of the correct inflation pressures.



Wheel Marking

#### ! Warning

Incorrect tyre inflation will cause abnormal tread wear and instability problems that may lead to loss of control and an accident.

Under-inflation may result in the tyre slipping on, or coming off the rim. Over-inflation will cause instability and accelerated tread wear.

Both conditions are dangerous as they may cause loss of control leading to an accident.

### Tyre Wear

As the tyre tread wears down, the tyre becomes more susceptible to punctures and failure. It is estimated that 90% of all tyre problems occur during the last 10% of tread life (90% worn). It is therefore not recommended to use tyres until they are worn to their minimum.

### Minimum Recommended Tread Depth

In accordance with the periodic maintenance chart, measure the depth of the tread with a depth gauge, and replace any tyre that has worn to, or beyond the minimum allowable tread depth specified in the table below:

Under 130 km/h (80 mph)	2 mm (0.08 in)
Over 130 km/h (80 mph)	Rear 3 mm (0.12 in) Front 2 mm (0.08 in)

#### ! Warning

This motorcycle must not be operated above the legal road speed limit except in authorised closed-course conditions.

## Maintenance and Adjustment

---

### Warning

Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed-course racetracks. High-speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high-speed riding and are familiar with the motorcycle's characteristics in all conditions. High-speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

### Warning

Operation with excessively worn tyres is hazardous and will adversely affect traction, stability and handling which may lead to loss of control and an accident.

When tubeless tyres become punctured, leakage is often very slow. Always inspect tyres very closely for punctures. Check the tyres for cuts, embedded nails or other sharp objects. Operation with punctured or damaged tyres will adversely affect motorcycle stability and handling which may lead to loss of control or an accident.

Check the rims for dents or deformation. Operation with damaged or defective wheels or tyres is dangerous and loss of motorcycle control or an accident could result.

Always consult your authorised Triumph dealer for tyre replacement, or for a safety inspection of the tyres.

### Tyre Replacement

All Triumph motorcycles are carefully and extensively tested in a range of riding conditions to ensure that the most effective tyre combinations are approved for use on each model. It is essential that approved tyres, fitted in approved combinations, are used when purchasing replacement tyres. The use of non-approved tyres, or approved tyres in non-approved combinations, may lead to motorcycle instability and an accident. See the Specification section for details of approved tyre combinations. Always have tyres fitted and balanced by your authorised Triumph dealer who has the necessary training and skills to ensure safe, effective fitment.

### Warning

If a tyre sustains a puncture, the tyre must be replaced. Failure to replace a punctured tyre, or operation with a repaired tyre can lead to instability, loss of control or an accident.



## Maintenance and Adjustment

---

### Warning

Do not install tube-type tyres on tubeless rims. The bead will not seat and the tyres could slip on the rims, causing rapid tyre deflation that may result in a loss of vehicle control and an accident. Never install an inner tube inside a tubeless tyre. This will cause friction inside the tyre and the resulting heat build-up may cause the tube to burst resulting in rapid tyre deflation, loss of vehicle control and an accident.

### Warning

If tyre damage is suspected, such as after striking the kerb, ask your authorised Triumph dealer to inspect the tyre both internally and externally. Remember, tyre damage may not always be visible from the outside. Operation of the motorcycle with damaged tyres could lead to loss of control and an accident.

### Warning

When replacement tyres are required, consult your authorised Triumph dealer who will arrange for the tyres to be selected, in a correct combination, from the approved list and fitted according to the tyre manufacturer's instructions.

When tyres are replaced, allow time for the tyres to seat to the rim (approximately 24 hours). During this seating period, ride cautiously as an incorrectly seated tyre could cause loss of control or an accident.

Initially, the new tyres will not produce the same handling characteristics as the worn tyres and the rider must allow adequate riding distance (approximately 100 miles) to become accustomed to the new handling characteristics.

24 hours after fitting, the tyre pressures must be checked and adjusted, and the tyres examined for correct seating. Rectification must be carried out as necessary.

The same checks and adjustments must also be carried out when 100 miles have been travelled after fitting.

Use of a motorcycle with incorrectly seated tyres, incorrectly adjusted tyre pressures, or when not accustomed to its handling characteristics may lead to loss of control and an accident.

## Maintenance and Adjustment

---

### Warning

Tyres that have been used on a rolling road dynamometer may become damaged. In some cases, the damage may not be visible on the external surface of the tyre. Tyres must be replaced after such use as continued use of a damaged tyre may lead to instability, loss of control and an accident.

### Warning

Accurate wheel balance is necessary for safe, stable handling of the motorcycle. Do not remove or change any wheel balance weights. Incorrect wheel balance may cause instability leading to loss of control and an accident.

When wheel balancing is required, such as after tyre replacement, see your authorised Triumph dealer.

Only use self-adhesive weights. Clip on weights may damage the wheel and tyre resulting in tyre deflation, loss of control and an accident.

## Battery

### Warning

Under some circumstances, the battery can give off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using the battery in an enclosed space.

The battery contains sulphuric acid (battery acid). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.

If battery acid gets on your skin, flush with water immediately.

If battery acid gets in your eyes, flush with water for at least 15 minutes and **SEEK MEDICAL ATTENTION IMMEDIATELY.**

If battery acid is swallowed, drink large quantities of water and **SEEK MEDICAL ATTENTION IMMEDIATELY.**

**KEEP BATTERY ACID OUT OF THE REACH OF CHILDREN.**

### Warning


The battery contains harmful materials. Always keep children away from the battery whether or not it is fitted in the motorcycle.

Do not attach jump leads to the battery, touch the battery cables together or reverse the polarity of the cables as any of these actions may cause a spark which would ignite battery gases causing a risk of personal injury.

## Maintenance and Adjustment


### Battery Removal

#### Daytona 675



1. Battery
2. Negative (black) terminal
3. Positive (red) terminal
4. Battery strap

#### Street Triple



1. Battery
2. Negative (black) terminal
3. Positive (red) terminal
4. Battery strap

Remove the rider's seat.

Remove the battery strap.

Disconnect the battery leads, negative (black) lead first.

Take the battery out of the case.

### **Warning**

Ensure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark, which would ignite battery gases causing a risk of personal injury.

### Battery Disposal

Should the battery ever require replacement, the original battery must be handed to a recycling agent who will ensure that the dangerous substances from which the battery is manufactured do not pollute the environment.

### Battery Maintenance

Clean the battery using a clean, dry cloth. Be sure that the cable connections are clean.

### **Warning**

The battery acid is corrosive and poisonous and will cause damage to unprotected skin. Never swallow battery acid or allow it to come into contact with the skin. To prevent injury, always wear eye and skin protection when handling the battery.

The battery is a sealed type and does not require any maintenance other than checking the Voltage and routine recharging when required, such as during storage.

It is not possible to adjust the battery acid level in the battery; the sealing strip must not be removed.

## Maintenance and Adjustment

---

### Battery Discharge

#### Caution

The charge level in the battery must be maintained to maximise battery life. Failure to maintain the battery charge level could cause serious internal damage to the battery.

Under normal conditions, the motorcycle charging system will keep the battery fully charged. However, if the motorcycle is unused, the battery will gradually discharge due to a normal process called self discharge; the clock, engine control module (ECM) memory, high ambient temperatures, or the addition of electrical security systems or other electrical accessories will all increase this rate of battery discharge. Disconnecting the battery from the motorcycle during storage will reduce the rate of discharge.

### Battery Maintenance During Motorcycle Storage

During storage or infrequent use of the motorcycle, inspect the battery Voltage weekly using a digital multimeter. Follow the manufacturer's instructions supplied with the meter.

Should the battery Voltage fall below 12.7 Volts, the battery should be charged (see page 100).

Allowing a battery to discharge or leaving it discharged for even a short period of time causes sulphation of the lead plates. Sulphation is a normal part of the chemical reaction inside the battery, however over time the sulphate can crystallise on the plates making recovery difficult or impossible. This

permanent damage is not covered by the motorcycle warranty, as it is not due to a manufacturing defect.

Keeping the battery fully charged reduces the likelihood of it freezing in cold conditions. Allowing a battery to freeze will cause serious internal damage to the battery.

### Battery Charging

For help with selecting a battery charger, checking the battery Voltage or battery charging, contact your local authorised Triumph dealer.

#### Warning

The battery gives off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using the battery in an enclosed space.

The battery contains sulphuric acid (battery acid). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.

If battery acid gets on your skin, flush with water immediately.

If battery acid gets in your eyes, flush with water for at least 15 minutes and SEEK MEDICAL ATTENTION IMMEDIATELY.

If battery acid is swallowed, drink large quantities of water and SEEK MEDICAL ATTENTION IMMEDIATELY.

KEEP BATTERY ACID OUT OF THE REACH OF CHILDREN.

## Maintenance and Adjustment

### Caution

Do not use an automotive quick charger as it may overcharge and damage the battery.

Should the battery Voltage fall below 12.7 Volts, the battery should be charged using a Triumph approved battery charger. Always follow the instructions supplied with the battery charger.

For extended periods of storage (beyond two weeks) the battery should be removed from the motorcycle and kept charged using a Triumph approved maintenance charger.

Similarly, should the battery charge fall to a level where it will not start the motorcycle, remove the battery from the motorcycle before charging.

### Battery Installation

### Warning

Ensure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark, which would ignite battery gases causing a risk of personal injury.

Place the battery in the battery case.

Reconnect the battery, positive (red) lead first. Apply a light coat of grease to the terminals to prevent corrosion.


Cover the positive terminal with the protective cap.

Refit the battery strap.

Refit the rider's seat.

### Fuse Box

#### Daytona 675



**Arrowed: Fuse Box**

The fuse box is located beneath the left hand cockpit infill panel.


To allow access to the fuse box, the cockpit infill panel must be removed.

### Warning

Always replace blown fuses with new ones of the correct rating (as specified on the fuse box cover) and never use a fuse of higher rating. Use of an incorrect fuse could lead to an electrical problem, resulting in motorcycle damage, loss of motorcycle control and an accident.


## Maintenance and Adjustment

### Street Triple



Arrowed: Fuse Box


The fuse box is located beneath the fuel tank. To access the fuse box, remove the seat. Remove the fuel tank support from its location in the seat base.



1. Fuel tank support
2. Seat

Remove the front fuel tank fixings and pivot the fuel tank upwards at the front. While holding the fuel tank in the raised position,

locate the fuel tank support into the fuel tank fixing points on the frame and fuel tank.



1. Fuel tank support
2. Fuel tank
3. Fixing point, fuel tank
4. Fixing point, frame

### Warning

Always replace blown fuses with new ones of the correct rating (as specified on the fuse box cover) and never use a fuse of higher rating. Use of an incorrect fuse could lead to an electrical problem, resulting in motorcycle damage, loss of motorcycle control and an accident.

## Maintenance and Adjustment


### Fuse Identification

A blown fuse is indicated when all of the systems protected by that fuse become inoperative. When checking for a blown fuse, use the tables to establish which fuse has blown.

The fuse identification numbers listed in the tables correspond with those printed on the fuse box cover, as shown. Spare fuses are located at right angles to the main fuses and should be replaced if used.

### Daytona 675


Circuit Protected	Position	Rating (Amps)
Dip and main beam headlights, starter relay	1	15
Ignition switch, starter circuit	2	10
Auxiliary lighting	3	5
Horn, indicators, alarm	4	10
Cooling fan	5	15
Engine management	6	20



1. Fuse box
2. Fuse box cover
3. Spare fuses

### Street Triple

Circuit Protected	Position	Rating (Amps)
Dip and main beam headlights, starter relay	1	20
Ignition switch, starter circuit	2	10
Auxiliary lighting	3	5
Horn, indicators, alarm	4	10
Cooling fan	5	15
Engine management	6	20



1. Fuse box
2. Fuse box cover
3. Spare fuses

#### Note:

- The starter solenoid has an additional 30 Amp fuse, attached directly to the solenoid, beneath the rider's seat.

## Maintenance and Adjustment

### Headlights

#### Headlights

#### Warning

Adjust road speed to suit the visibility and weather conditions in which the motorcycle is being operated.

Ensure that the beams are adjusted to illuminate the road surface sufficiently far ahead without dazzling oncoming traffic. An incorrectly adjusted headlight may impair visibility causing an accident.

#### Warning

Never attempt to adjust a headlight beam when the motorcycle is in motion.

Any attempt to adjust a headlight beam when the motorcycle is in motion may result in loss of control and an accident.


#### Caution

If the motorcycle is to be used under closed-course conditions, you may be asked to tape the visible outer surface of the headlight.

When taped, the headlight will overheat and distort the outer surface. Therefore, to avoid headlight distortion, always disconnect the headlights when they are taped for use under closed-course conditions.

### Headlight Adjustment - Daytona 675

Each headlight can be adjusted by means of vertical and horizontal adjustment screws located on the rear of each headlight.



1. Horizontal adjustment screw (left hand)
2. Vertical adjustment screw (left hand)
3. Horizontal adjustment screw (right hand)
4. Vertical adjustment screw (right hand)
5. Pivot screws (DO NOT adjust these screws)

Switch the headlight dipped beam on.

#### Caution

Do not adjust the pivot screws as this will cause the headlight reflector to become detached from the pivot screw, leading to irreparable damage to the headlight.



## Maintenance and Adjustment

---

Turn the vertical adjustment screws on each headlight clockwise to raise the beam or anti-clockwise to lower the beam.


On the right hand headlight turn the horizontal adjustment screw clockwise to move the beam to the left or anti-clockwise to move the beam to the right.

On the left hand headlight turn the horizontal adjustment screw clockwise to move the beam to the right or anti-clockwise to move the beam to the left.

Switch the headlights off when the beam settings are satisfactory.

### Headlight Adjustment - Street Triple

#### Vertical Adjustment



#### 1. Vertical beam adjuster cover fixings

The vertical beams of the left hand and right hand headlights can only be adjusted together. Independent adjustment is not possible.

Switch the headlight dipped beam on.

Remove the adjuster cover.

Slacken the clamp bolt sufficient to allow restricted movement of the headlights.

Adjust the position of the headlights to give the required beam setting.

Tighten the clamp bolt to **15 Nm**.


Re-check the headlight beam settings.

Switch the headlights off when both beam settings are satisfactorily set.

Refit the adjuster cover.

## Maintenance and Adjustment

### Horizontal Adjustment



#### 1. Horizontal beam adjusters

The horizontal beams of both headlights can be adjusted individually. The same procedure is used to adjust either headlight.

Switch the headlight dipped beam on.

Slacken the headlight bowl fixing.

Adjust the horizontal position of the headlight to give the required beam setting.

Tighten the clamp bolt to **15 Nm**.

Repeat for the second headlight.

Re-check the headlight beam settings.

Switch the headlights off when both beam settings are satisfactorily set.

### Headlight Bulb Replacement - Daytona 675


#### Caution

The use of non-approved headlight bulbs may result in damage to the headlight lens.

Use a genuine Triumph supplied headlight bulb as specified in the Triumph Parts Catalogue.

Always have replacement headlight bulbs installed by an authorised Triumph dealer.

It is not necessary to remove the headlight when bulb replacement becomes necessary.



#### 1. Headlight unit

#### 2. Bulb retainer (right hand shown)

#### Warning

The bulbs become hot during use. Always allow sufficient time for the bulb to cool before handling. Avoid touching the glass part of the bulb. If the glass is touched or gets dirty, clean with alcohol before reuse.

## Maintenance and Adjustment

To replace a bulb:

Remove the rider's seat.

Disconnect the battery, negative (black) lead first.

Remove the four screws and remove the bulb cover from the bulb to be replaced.


Disconnect the multi-plug from the bulb retainer.

Detach the bulb retainer from the headlight assembly by rotating it counter-clockwise.

Remove the bulb from the bulb retainer.

Installation is the reverse of the removal procedure.

### Position Lamp Bulb Replacement




1. Bulb holder
2. Position lamp bulb

The position lamps are fitted to the left and right of each headlight. To replace a bulb, remove the two screws and remove the bulb cover, detach the rubber retainer from the headlight and pull out the bulb.

Installation is the reverse of the removal procedure.

### Headlight Bulb Replacement - Street Triple



1. Headlight bulb
2. Bulb clip
3. Position lamp bulb

### Warning

The bulbs become hot during use. Always allow sufficient time for the bulbs to cool before handling. Avoid touching the glass part of the bulb. If the glass is touched or gets dirty, clean with alcohol before reuse.

Remove the seat.

Disconnect the battery, negative (black) lead first.

Undo the fixing securing the headlight clamp to the headlight body.

Support the headlight while removing the clamp.

Remove the headlight from its bowl while supporting it to prevent the cables from being over extended.

## Maintenance and Adjustment

Disconnect the multi-pin electrical connector from the bulb to be replaced and remove the rubber cover.

Detach the wire retainer from its clip (do not remove the screw) then remove the bulb from the light unit.

### Position Lamp Bulb Replacement

To remove the position lamp bulb:

Without pulling the wires, ease the bulb holder from its socket. The bulb is removed from its holder by pulling gently upwards.

Installation for both bulbs is the reverse of the removal procedure. Tighten the headlight clamp to **4 Nm**.

### Warning

Do not reconnect the battery until the assembly process has been completed. Premature battery reconnection could result in ignition of the battery gases causing risk of injury.

### Caution

When reconnecting the battery, connect the positive (red) lead first.


## Rear Light

### Rear Light Replacement - Both Models

The rear light unit is a sealed, maintenance free LED unit.

## Direction Indicator Lights

### Bulb Replacement - Daytona 675




1. Indicator lens
2. Securing screw

The lens on each indicator light is held in place by a securing screw located in the body of the light.

Release the screw and remove the lens to gain access to the bulb for replacement.

## Maintenance and Adjustment

### Bulb Replacement - Street Triple



1. Indicator lens
2. Securing screw

The lens on each indicator light is held in place by a securing screw located in the lens of the light.

Release the screw and remove the lens to gain access to the bulb for replacement.

### Licence Plate Light

#### Bulb Replacement - Both Models

Carefully remove the rubber bulb retainer from the back of the number plate light unit and detach the bulb.

#### Caution

To avoid cable damage, do not pull the bulb retainer using the cables.

Installation is the reverse of the removal procedure.

## Maintenance and Adjustment

---

### Cleaning

Frequent, regular cleaning is an essential part of the maintenance of your motorcycle. If regularly cleaned, the appearance will be preserved for many years. Cleaning with cold water containing an automotive cleaner is essential at all times but particularly so after exposure to sea breezes, sea water, dusty or muddy roads and in winter when roads are treated for ice and snow. Do not use household detergent, as the use of such products will lead to premature corrosion.

Although, under the terms of your motorcycle warranty, cover is provided against the corrosion of certain items, the owner is expected to observe this reasonable advice which will safeguard against corrosion and enhance the appearance of the motorcycle.

### Preparation for Washing

Before washing, precautions must be taken to keep water off the following places.

Rear opening of the exhausts: Cover with a plastic bag secured with rubber bands.

Clutch and brake levers, switch housings on the handlebar: Cover with plastic bags.

Ignition switch and steering lock: Cover the keyhole with tape.

Remove any items of jewellery such as rings, watches, zips or belt buckles, which may scratch or otherwise damage painted or polished surfaces.

Use separate cleaning sponges or cleaning cloths for washing painted/polished surfaces and chassis areas. Chassis areas (such as wheels and under mudguards) will be exposed to more abrasive road grime and dust, which may then scratch painted or polished surfaces, if the same sponge or cleaning cloths are used.

## Maintenance and Adjustment

---

### Where to be Careful

Avoid spraying water with any great force near the following places:

- Instruments;
- Brake cylinders and brake calipers;
- Under the fuel tank;
- Headstock bearings;
- Air intake duct above the headlights.

#### Caution

Any water sprayed around the air intake duct could enter the airbox and engine, causing damage to both items.

#### Caution

Use of high-pressure spray washers is not recommended. When using pressure washers, water may be forced into bearings and other components causing premature wear from corrosion and loss of lubrication.

### Note:

- **Use of soaps that are highly alkaline will leave a residue on painted surfaces, and may also cause water spotting. Always use a low alkaline soap to aid the cleaning process.**

### After Washing

Remove the plastic bags and tape, and clear the air intakes.

Lubricate the pivots, bolts and nuts.

Test the brakes before motorcycle operation.

Start the engine and run it for 5 minutes. Ensure adequate ventilation for the exhaust fumes.

Use a dry cloth to absorb water residue. Do not allow water to stand on the machine as this will lead to corrosion.

#### Warning

Never wax or lubricate the brake discs. Loss of braking power and an accident could result. Clean the disc with a proprietary brand of oil-free brake disc cleaner.

### Unpainted Aluminium Items

Items such as brake and clutch levers must be correctly cleaned to preserve their appearance.

Use a proprietary brand of aluminium cleaner which does not contain abrasive or caustic elements.

Clean aluminium items regularly, in particular after use in inclement weather, where the components must be hand washed and dried each time the machine is used.

Warranty claims due to inadequate maintenance will not be allowed.

## Maintenance and Adjustment

---

### Cleaning of the Exhaust System

All parts of the exhaust system of your motorcycle must be cleaned regularly to avoid a deterioration of its appearance.

#### Note:

- **The exhaust system must be cool before washing to prevent water spotting.**

### Washing

Prepare a mixture of cold water and mild automotive cleaner. Do not use a highly alkaline soap as commonly found at commercial car washes because it leaves a residue.

Wash the exhaust system with a soft cloth. Do not use an abrasive scouring pad or steel wool. They will damage the finish.

Rinse the exhaust system thoroughly.

Ensure no soap or water enters the mufflers.

### Drying

Dry the exhaust system as far as possible with a soft cloth. Do not run the engine to dry the system or spotting will occur.

### Protecting

When the exhaust system is dry, rub 'Motorex 645 Clean and Protect' into the surface.

#### **Caution**

The use of products containing silicone will cause discolouration of the chrome and must not be used. Similarly, the use of abrasive cleaners and polishes will damage the system and must not be used.

It is recommended that regular protection be applied to the system as this will both protect and enhance the system's appearance.



---

### STORAGE

#### Preparation for Storage

Clean and dry the entire vehicle thoroughly.

Fill the fuel tank with the correct grade of unleaded fuel and add a fuel stabiliser (if available), following the fuel stabiliser manufacturer's instructions.

 **Warning**

Petrol is extremely flammable and can be explosive under certain conditions. Turn the ignition switch off. Do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.

Remove the spark plug from each cylinder and put several drops (5 ml) of engine oil into each cylinder. Cover the spark plug holes with a piece of cloth or rag. With the engine stop switch in the RUN position, push the starter button for a few seconds to coat the cylinder walls with oil. Install the spark plugs, tightening to **12 Nm**.

Change the engine oil and filter (see page 72).

Check and if necessary correct the tyre pressures (see page 118).

Set the motorcycle on a stand so that both wheels are raised off the ground. (If this cannot be done, put boards under the front and rear wheels to keep dampness away from the tyres.)

Spray rust inhibiting oil (there are a host of products on the market and your dealer will be able to offer you local advice) on all

unpainted metal surfaces to prevent rusting. Prevent oil from getting on rubber parts, brake discs or in the brake calipers.

Lubricate and if necessary adjust the drive chain (see page 87).

Make sure the cooling system is filled with a 50% mixture of anti-freeze and distilled water solution (see page 74).

Remove the battery, and store it where it will not be exposed to direct sunlight, moisture, or freezing temperatures. During storage it should be given a slow charge (one ampere or less) about once every two weeks (see page 98).

Store the motorcycle in a cool, dry area, away from sunlight, and with a minimum daily temperature variation.

Put a suitable porous cover over the motorcycle to keep dust and dirt from collecting on it. Avoid using plastic or similar non-breathable, coated materials that restrict air flow and allow heat and moisture to accumulate.

## Storage

---

### Preparation after Storage

Install the battery (if removed) (see page 101).

If the motorcycle has been stored for more than four months, change the engine oil (see page 72).

Check all the points listed in the Daily Safety Checks section.

Before starting the engine, remove the spark plugs from each cylinder.

Put the side stand down.

Crank the engine on the starter motor several times until the oil pressure light goes out.

Replace the spark plugs, tightening to **12 Nm**, and start the engine.

Check and if necessary correct the tyre pressures (see page 118).

Clean the entire vehicle thoroughly.

Check the brakes for correct operation.

Test ride the motorcycle at low speeds.

## Specifications

### SPECIFICATIONS

	<b>Daytona 675</b>	<b>Street Triple</b>
<b>Dimensions</b>		
Overall Length .....	2,010 mm (79.1 in)	2,000 mm (78.7 in)
Overall Width .....	700 mm (27.5 in)	750 mm (29.5 in)
Overall Height .....	1,120 mm (44.1 in)	1,165 mm (45.8 in)
Wheelbase .....	1,395 mm (54.9 in)	1,390 mm (54.7 in)
Seat Height .....	825 mm (32.5 in)	810 mm (31.8 in)
<b>Weights</b>		
Dry Weight .....	165 kg	167 kg
Maximum Payload .....	195 kg	195 kg
<b>Engine</b>		
Type .....	In-line 3 cylinder	In-line 3 cylinder
Displacement .....	674.8 cc	674.8 cc
Bore x Stroke .....	74 x 52.3 mm	74 x 52.3 mm
Compression Ratio .....	12.65:1	12.65:1
Cylinder Numbering .....	Left to Right	Left to Right
Cylinder Sequence .....	1 at left	1 at left
Firing Order .....	1-2-3	1-2-3
Starting System .....	Electric Starter	Electric Starter
<b>Performance</b>		
Maximum Power (DIN 70020) .....	125 PS (123 bhp) at 12,500 rpm	108.2 PS (106.7 bhp) at 11,700 rpm
Maximum Torque .....	72 Nm (53.3 ft.lbf) at 11,750 rpm	68 Nm (50.1 ft.lbf) at 9,200 rpm

## Specifications

---

	<b>Daytona 675</b>	<b>Street Triple</b>
<b>Lubrication</b>		
Lubrication.....	Pressure Lubrication (wetsump)	Pressure Lubrication (wetsump)
Engine Oil Capacities		
Dry Fill.....	3.0 litres	3.0 litres
Oil/Filter Change .....	2.6 litres	2.6 litres
Oil Change Only.....	2.4 litres	2.4 litres
<b>Cooling</b>		
Coolant Type.....	Mobil Antifreeze	Mobil Antifreeze
Water/Anti-freeze ratio.....	50/50	50/50
Coolant Capacity.....	2.4 litres	2.4 litres
Thermostat Opens (nominal) .....	71°C	71°C
<b>Fuel System</b>		
Type.....	Electronic Fuel Injection	Electronic Fuel Injection
Injectors.....	Solenoid Operated	Solenoid Operated
Fuel Pump.....	Submerged Electric	Submerged Electric
Fuel Pressure (nominal).....	3 bar	3 bar
<b>Fuel</b>		
Type.....	95 RON unleaded	91 RON unleaded
Tank Capacity .....	17.4 litres	17.4 litres

## Specifications

	<b>Daytona 675</b>	<b>Street Triple</b>
<b>Ignition</b>		
Ignition System . . . . .	Digital Inductive	Digital Inductive
Electronic Rev Limiter (r/min) . . . . .	14,000 (r/min)	13,000 (r/min)
Spark Plug . . . . .	NGK CR9EK	NGK CR9EK
Spark Plug Gap . . . . .	0.7 mm	0.7 mm
Gap Tolerance . . . . .	+0.05/-0.1 mm	+0.05/-0.1 mm
<b>Transmission</b>		
Transmission Type . . . . .	6 Speed, Constant Mesh	6 Speed, Constant Mesh
Clutch Type . . . . .	Wet, Multi-Plate	Wet, Multi-Plate
Final Drive Chain . . . . .	RK O-ring	RK O-ring
Primary Drive Ratio . . . . .	1.848:1 (46/85)	1.848:1 (46/85)
Gear Ratios:		
Final Drive Ratio . . . . .	2.937:1 (16/47)	2.937:1 (16/47)
1st . . . . .	2.615:1 (13/34)	2.615:1 (13/34)
2nd . . . . .	1.857:1 (21/39)	1.857:1 (21/39)
3rd . . . . .	1.565:1 (23/36)	1.565:1 (23/36)
4th . . . . .	1.350:1 (20/27)	1.350:1 (20/27)
5th . . . . .	1.238:1 (21/26)	1.238:1 (21/26)
6th . . . . .	1.136:1 (22/25)	1.136:1 (22/25)

## Specifications

---

	<b>Daytona 675</b>	<b>Street Triple</b>
<b>Tyres</b>		
Tyre Pressures (Cold):		
Front .....	2.35 bar (34 lb/in <sup>2</sup> )	2.35 bar (34 lb/in <sup>2</sup> )
Rear .....	2.50 bar (36 lb/in <sup>2</sup> )	2.90 bar (42 lb/in <sup>2</sup> )
Front Size .....	120/70 ZR 17	120/70 ZR 17
Rear Size .....	180/55 ZR 17	180/55 ZR 17
Approved Tyres:		
Option 1, Front and Rear .....	Pirelli Dragon Supercorsa Pro	Dunlop Sportmax Qualifier
Option 2, Front and Rear .....	Michelin Pilot Power B	Pirelli Dragon Supercorsa Pro
Option 3, Front and Rear .....	Bridgestone BT014 G	Bridgestone BT014 G

### **Warning**

Use the recommended tyres **ONLY** in the combinations given. Do not mix tyres from different manufacturers or mix different specification tyres from the same manufacturers as this may result in loss of motorcycle control and an accident.

## Specifications

---

	<b>Daytona 675</b>	<b>Street Triple</b>
<b>Electrical Equipment</b>		
Battery Type . . . . .	YT7B - BS	YTX9 - BS
Battery Rating . . . . .	12 Volt, 7 Ah	12 Volt, 8 Ah
Alternator . . . . .	12 Volt, 33.5 Amp at 4,000 rpm	12 Volt, 33.5 Amp at 4,000 rpm
Headlight . . . . .	1 x 12 Volt, 55 watt, H7 Halogen (left hand side) 1 x 12 Volt, 65 watt, H9 Halogen (right hand side)	2 x 12 Volt, 55/60 watt, H4 Halogen
Tail/Brake Light . . . . .	LED	LED
Directional Indicator Lights . . . . .	12 Volt, 10 watt	12 Volt, 10 watt
<b>Frame</b>		
Rake . . . . .	23.9°	24.3°
Trail . . . . .	89.1 mm	95.3 mm

## Specifications

---

### All Models

#### Tightening Torques

Oil Filter .....	10 Nm
Oil Drain Plug .....	25 Nm
Spark Plug .....	12 Nm
Rear Wheel Spindle .....	110 Nm
Chain Adjuster Locknut .....	27 Nm

#### Fluids and Lubricants

Engine Oil .....	Semi or fully synthetic 10W/40 or 15W/50 motorcycle engine oil which meets specification API SH (or higher) and JASO MA, such as Mobil 1 Racing 4T
Brake and Clutch Fluid .....	Mobil Universal Brake and Clutch Fluid DOT 4
Coolant .....	Mobil Anti-freeze
Bearings and Pivots .....	Mobil Grease HP 222
Drive Chain .....	Mobil Chain Spray or Mobilube HD 80



**INDEX**

**A**

Accessories ..... 61

**B**

Battery ..... 98  
 Disposal ..... 99  
 Installation ..... 100  
 Maintenance ..... 99  
 Removal ..... 99  
 Battery Charging ..... 100  
 Brakes ..... 84  
 Brake and Clutch Lever Adjusters .. 40  
 Braking ..... 55  
 Disc Brake Fluid ..... 85  
 Fluid Level ..... 86  
 Light Switches ..... 87  
 Pad Wear Compensation ..... 85  
 Wear Inspection ..... 84

**C**

Cleaning ..... 110  
 After Washing ..... 111  
 Drying ..... 112  
 Exhaust System ..... 112  
 Preparation ..... 110  
 Protecting ..... 112  
 Unpainted Aluminium Items ..... 111  
 Washing ..... 112  
 Where to be Careful ..... 111  
 Clock/Trip Computer ..... 25  
 Clutch ..... 80  
 Adjustment ..... 80  
 Inspection ..... 80  
 Coolant Temperature Gauge ..... 27  
 Cooling System ..... 74  
 Change ..... 77  
 Corrosion Inhibitors ..... 74  
 Level Adjustment ..... 76  
 Level Inspection ..... 75

**D**

Dimensions ..... 115  
 Direction Indicator Lights ..... 108  
 Drive Chain ..... 81  
 Lubrication ..... 81  
 Movement Adjustment ..... 82  
 Movement Inspection ..... 82  
 Wear Inspection ..... 83

**E**

Electrical Equipment ..... 119  
 Engine  
 Serial Number ..... 19  
 Specifications ..... 115  
 To Start the Engine ..... 52  
 To Stop the Engine ..... 52  
 Engine Oil ..... 71  
 Disposal of Oil and Filters ..... 74  
 Grade and Specification ..... 74  
 Oil Level Inspection ..... 71

**F**

Fluids and Lubricants ..... 120  
 Frame ..... 119  
 Front Suspension ..... 90  
 Compression Damping Adjustment . 93  
 Fork Inspection ..... 90  
 Rebound Damping Adjustment .... 92  
 Setting Chart ..... 91  
 Spring Pre-Load Adjustment ..... 92  
 Fuel ..... 116  
 Fuel Requirement ..... 43  
 Filling the Fuel Tank ..... 45  
 Fuel Grade ..... 43  
 Fuel Tank Cap ..... 44  
 Fuel System ..... 116  
 Fuse Box ..... 101

## Index

---

### G

- Gear Change Lights . . . . . **31**
- Gears
  - Changing Gears . . . . . **54**

### H

- Headlights . . . . . **104**
  - Adjustment . . . . . **104**
  - Bulb Replacement . . . . . **106**
  - Position Lamp . . . . . **108**
- Helmet and Clothing . . . . . **6**

### I

- Ignition . . . . . **117**
  - Key . . . . . **39**
  - Switch/Steering Lock . . . . . **39**
- Instrument Panel Layout . . . . . **23**

### L

- Lap Timer . . . . . **27**
- Left Handlebar Switches . . . . . **42**
  - Direction Indicator Switch . . . . . **43**
  - Headlight Dip Switch . . . . . **42**
  - Horn Button . . . . . **43**
  - Pass Button . . . . . **43**
- Licence Plate Light . . . . . **109**
- Lubrication . . . . . **116**

### O

- Odometer/Trip Meter . . . . . **24**

### P

- Performance . . . . . **115**

### R

- Rear Light . . . . . **108**
- Rear Seat . . . . . **48**
- Rider's Seat . . . . . **47**
- Right Handlebar Switches . . . . . **41**
  - Engine Stop Switch . . . . . **41**
  - Starter Button . . . . . **42**
- Running-In . . . . . **48**

### S

- Safety . . . . . **5**
  - Daily Checks . . . . . **49**
  - Fuel and Exhaust Fumes . . . . . **5**
  - Handlebars and Footrests . . . . . **9**
  - Maintenance/Equipment . . . . . **7**
  - Motorcycle . . . . . **5**
  - Parking . . . . . **6**
  - Parts and Accessories . . . . . **7**
  - Riding . . . . . **8**
- Seat Lock . . . . . **47**
- Speedometer . . . . . **24**
- Stand . . . . . **46**
  - Side Stand . . . . . **46**
- Steering/Wheel Bearings . . . . . **89**
  - Inspection . . . . . **89**
- Storage
  - Preparation after Storage . . . . . **114**
  - Preparation for Storage . . . . . **113**

## Index

---

### T

Tachometer .....	24
Throttle Control .....	77
Tightening Torques .....	120
Tool Kit .....	45
Transmission .....	117
Tyres .....	94
Inflation Pressures .....	95
Minimum Tread Depth .....	95
Replacement .....	96

### V

Vehicle Identification Number .....	19
-------------------------------------	----

### W

Warning Lights .....	37
Warnings	
Warning Label Locations .....	10
Warning Labels .....	2
Warnings, Cautions and Notes .....	1
Weights .....	115
Windscreen Cleaning .....	88

## Index

---

This page intentionally left blank